Mandis shop

Epson 1515068

Original		Replacement	
	Power		Power
	Source Search		AV
	Computer		Red
	Video		Green
	USB		Yellow
	A/V Mute		Mute
	1		1
	Freeze		Pause
	2		2
	User		Media
	3		3
	Auto		Info
	4		4
	Aspect		Format
	5		5
	Color Mode		Options
	6		6

Original		Replacement	
	Page Up		Ch +
	7		7
	Page Down		Ch -
	E-Zoom+		>>
	8		8
	E-Zoom-		<<
	0		0
	Pointer		Smart
	9		9
	Vol-		Vol -
	Vol+		Vol +
	?/Help		D. Menu
	Menu		Menu
	Esc		Exit
	Up		Up
	Left		Left
	Enter		Ok

Original	Replacement	Original	Replacement
Right	Right		
Down	Down		