Original	Replacement
Mute	Mute / Dimmer
Power Video	Shift + Power
Power	Power
[ ]	Picture / Format
[i+]	Info / Angle
→ ←	Smart / List
[ ]	Sleep / Timer
Text	Text / Goto
/	Setup / OPT /
Input	AV / Input / RDS
[I]	Shift + Guide / EPG / -/--
/	D. Menu / Top
↑	Zoom / Size
<<	<< / Tune-
Play	Play / Slow
>>	>> / Tune+
CH+	Shift + CH+ / Page+

Original	Replacement
[>I <]	Display / Media
CH-	Shift + CH- /
Stop	Stop / Hold
Pause	Pause / Step / Freeze
Rec	Rec / Rec Mode
1	1
2	2
3	3
4	4
5	5
6	6
7	7
8	8
9	9
-/--	Guide / EPG / -/--
0	0
Recall	Back / Return

Original	Replacement	Original	Replacement
Red	Red / Netflix / Search		
Green	Green / APP / Repeat		
Yellow	Yellow / YouTube / Repeat		
Blue	Blue / Prime Video / Random		
Up	Up		
Left	Left		
OK	OK		
Right	Right		
Down	Down		
Vol +	Vol +		
Progr +	CH+ / Page+		
Menu	Menu / Home		
Vol -	Vol -		
Progr -	CH- / Page-		

Original	Replacement	Original	Replacement
Power Video	Power		
→ ←	Smart / List		
[O]	Sleep / Timer		
<<	<< / Tune-		
Play	Play / Slow		
>>	>> / Tune+		
CH+	CH+ / Page+		
CH-	CH- / Page-		
Stop	Stop / Hold		
Pause	Pause / Step / Freeze		
Rec	Rec / Rec Mode		

Original	Replacement	Original	Replacement
Power Video	Power		
→ ←	Smart / List		
[O]	Sleep / Timer		
<<	<< / Tune-		
Play	Play / Slow		
>>	>> / Tune+		
CH+	CH+ / Page+		
CH-	CH- / Page-		
Stop	Stop / Hold		
Pause	Pause / Step / Freeze		
Rec	Rec / Rec Mode		

Original	Replacement	Original	Replacement
Power Video	Power		
→ ←	Smart / List		
[O]	Sleep / Timer		
<<	<< / Tune-		
Play	Play / Slow		
>>	>> / Tune+		
CH+	CH+ / Page+		
CH-	CH- / Page-		
Stop	Stop / Hold		
Pause	Pause / Step / Freeze		
Rec	Rec / Rec Mode		