Original		Replacement	
	Power		Power
SLEEP	Sleep	PROG SLEEP	Sleep
CLOCK/ TIMER	Clock/Timer	TIMER AV	AV
PLAY/ REC	Timer Play/Rec	A	Red
PROGRAM/ -CLEAR	Program/Clear	B	Green
CD PLAY MODE	CD Play Mode	C	Yellow
CD REC MODE	CD Rec Mode	D	Blue
1	1	1	1
2	2	2	2
3	3	3	3
4	4	4	4
5	5	5	5
6	6	6	6
7	7	7	7
8	8	8	8
9	9	9	9
0	0	0	0

Original		Replacement	
≥10	≥10	-/-- GUIDE	Guide
CD ▶/II	CD Play/Pause	PLAY MODE ▶	Play
TUNER/ BAND	Tuner/Band	OK	Ok
TAPE ▶	Tape Play	II	Pause
STOP ■	Stop	■	Stop
VOL –	Vol -	VOL –	Vol -
+ VOL	Vol +	+ VOL	Vol +
FM MODE	FM Mode	◀	Left
TUNE MODE	Tune Mode	▶	Right
REW/∨ ⏮	I<<\/Down	⏮	I<<
REW/∨ ⏮	I<<\/Down	<<	<<
REW/∨ ⏮	I<<\/Down	▼	Down
∧/FF ⏭	>>I/Up	⏭	>>I
∧/FF ⏭	>>I/Up	>>	>>
∧/FF ⏭	>>I/Up	▲	Up
SOUND VIRTUALIZER	Sound Virtualize	SOUND DUAL	Dual
PRESET EQ	Preset EQ	HOME SMART	Smart

Original		Replacement	
BASS	Bass	CH –	Ch -
TREBLE	Treble	+ CH	Ch +
MUTING	Muting	MUTE	Mute
DISPLAY	Display	DISPLAY INFO	Info
DIMMER	Dimmer	APP MEDIA	Media

Original	Replacement