Mandis shop

Samsung AH59-00004B

Original		Replacement	
POWER	Power	POWER	Power
TIMER ON/OFF	Timer On/Off	TIMER SLEEP	Sleep / Timer
MUTE	Mute	DIMMER MUTE	Mute / Dimmer
SOUND MODE	Sound Mode	TITLE SOUND	Sound / Title
DISC SKIP	Disc Skip	FORMAT PICTURE	Picture / Format
PROGRAM /SET	Program/Set	HOME MENU	Menu / Home
AUX	Aux	RDS AV INPUT	AV / Input / RDS
DECK 1/2	Deck 1/2	PROGRAM TV/ RADIO	TV/Radio /
REPEAT CD	CD/Repeat	CD - STB 3	3
MONO/ST	Mono/St	PC FAV MARKER	Fav / Marker / PC
TUNER	Tuner/Band	TUNER 6	6
◀◀	<< Tape	TUNE- ◀◀	<< / Tune-
▶▶	>> Tape	TUNE+ ▶▶	>> / Tune+
■	Stop Tape	SHIFT + HOLD ■	Shift + Stop /
◀▶	<> Tape	TAPE 5	5
■	Stop CD	HOLD ■	Stop / Hold
▶II	Play/Pause CD	SLOW ▶	Play / Slow

Original		Replacement	
VOL.+	Vol+	+ VOL	Vol+
VOL.–	Vol-	VOL –	Vol-
CD ▶▶I	Up/CD >>I	▲	Up
CD I◀◀	Down/CDI<<	▼	Down
TUNING MODE	Tuning Mode	OK	OK

https://alle-fernbedienungen.de/en/Samsung/1064982-3896-replacement-remote-control-for-Samsung-AH5900004B.html