Original		Replacement	
POWER	Power		Power
OPEN /CLOSE	Open / Close	SURROUND	Eject / Surround
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD - STB 3	3
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
7	7	AUX - HDD 7	7
8	8	USB 8	8
9	9	BLUETOOTH 9	9
0	0	HDMI - SAT 0	0
+10	+10	-/-- GUIDE EPG	Guide / EPG / -/--
STEP	Step	SHIFT + STEP - FREEZE	Shift + Pause / Step /
SLOW	Slow	SHIFT + SLOW	Shift + Play /
ZOOM	Zoom	SIZE ZOOM	Zoom / Size
ANGLE	Angle	ANGLE INFO	Info / Angle

Original		Replacement	
PROG	Prog	PROGRAM TV/ RADIO	TV/ Radio /
SHUFFLE	Shuffle	Prime Video RANDOM	Blue / Prime Video / Random
VIDEO	Video	LIST SMART	Smart / List
REPEAT	Repeat	APP REPEAT	Green / APP / Repeat
REPEAT A-B	Repeat A-B	YouTube REPEAT A-B	Yellow / YouTube / Repeat
TITLE	Title	TITLE SOUND	Sound / Title
PBC	PBC	FORMAT PICTURE	Picture / Format
GOTO	Goto	GOTO TEXT	Text / Goto
L/R	L/R	TOP MENU D.MENU	D.Menu / Top
SUBTITLE	Subtitle	EQ SUBTITLE	Subtitle / EQ
SETUP	Setup	OPT-TOOLS SETUP	Setup / OPT /
	Up		Up
DISPLAY	Display	MEDIA DISPLAY	Display / Media
	Left		Left
ENTER	Enter	OK	OK
	Right		Right
MENU	Menu	HOME MENU	Menu / Home

Original		Replacement		Original		Replacement	
	Down		Down				
RETURN	Return	RETURN BACK	Back / Return				
VOL+	Vol +	VOL	Vol +				
MUTE	Mute	DIMMER MUTE	Mute / Dimmer				
<<	<<	TUNE-	<< / Tune-				
>>	>>	TUNE+	>> / Tune+				
STOP	Stop	HOLD	Stop / Hold				
VOL-	Vol -	VOL	Vol -				
AUDIO	Audio	LANG I/II AUDIO	Audio / Lang I/II				
I<<	I <<	PRESET-	I << / Preset-				
>>I	>>I	PRESET+	>>I / Preset+				
>II	Play / Pause	SLOW	Play / Slow				
>II	Play / Pause	STEP-FREEZE	Pause / Step / Freeze				