Original		Replacement	
	Power		Power
	Mute	DIMMER MUTE	Mute / Dimmer
	Open/Close	SURROUND	Eject / Surround
USB	USB	SHIFT + USB 8	Shift + 8
USB	USB	CH PAGE	CH+ / Page+
PROG	Prog	PROGRAM TV/RADIO	TV/Radio /
MARK	Mark	PC FAV MARKER	Fav / Marker / PC
CLEAR	Clear	CLEAR EXIT CANCEL	Exit / Cancel / Clear
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD-STB 3	3
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
7	7	AUX-HDD 7	7
8	8	USB 8	8
9	9	BLUETOOTH 9	9

Original		Replacement	
0	0	HDMI-SAT 0	0
10+	10+	-/-- GUIDE EPG	Guide / EPG / -/--
GOTO	Goto	GOTO TEXT	Text / Goto
	<<	TUNE-	<< / Tune-
VOL	Vol-	VOL	Vol-
VOL	Vol+	VOL	Vol+
	I<<	PRESET-	I<< / Preset-
	>>	TUNE+	>> / Tune+
	Play/Pause	SLOW	Play / Slow
	Play/Pause	STEP-FREEZE	Pause / Step / Freeze
	Stop	HOLD	Stop / Hold
	>>I	PRESET+	>>I / Preset+
MENU	Menu	HOME MENU	Menu / Home
	Up		Up
SETUP	Setup	OPT-TOOLS SETUP	Setup / OPT /
	Left		Left
ENTER	Enter	OK	OK

Original		Replacement		Original	Replacement
	Right		Right		
TITLE	Title	TITLE SOUND	Sound / Title		
	Down		Down		
OSD	OSD	MEDIA DISPLAY	Display / Media		
ZOOM	Zoom	SIZE ZOOM	Zoom / Size		
ANGLE	Angle	ANGLE INFO	Info / Angle		
AUDIO	Audio	LANG I/II AUDIO	Audio / Lang I/II		
SUB-T	Sub-T	EQ SUBTITLE	Subtitle / EQ		
REPEAT	Repeat	APP REPEAT	Green / APP / Repeat		
A-B	A-B	YouTube REPEAT A-B	Yellow / YouTube / Repeat		
SLOW	Slow	SHIFT +	SLOW Shift + Play /		
L/R	L/R	LIST SMART	Smart / List		
STEP	Step	SHIFT +	STEP - FREEZE Shift + Pause / Step /		
RETURN	Return	RETURN BACK	Back / Return		
VIDEO	Video	SHIFT +	VIDEO 4 Shift + 4		
VIDEO	Video	CH PAGE	CH- / Page-		
DEFAULT	Default	REC MODE	Rec / Rec Mode		