Mandis shop

IH6-IH8

Original		Replacement		Original	Replacement
alm. reset	Power/alm./reset		Power		
▶II	Play	SLOW ▶	Play / Slow		
▶II	Pause	STEP-FREEZE II	Pause / Step / Freeze		
◀◀	<<	TUNE- ◀◀	<< / Tune-		
▶▶	>>	TUNE+ ▶▶	>> / Tune+		
mute	Mute	DIMMER MUTE	Mute / Dimmer		
🔊	Vol+	+ VOL	Vol+		
🔉	Vol-	VOL −	Vol-		
presets	Preset	OPT-TOOLS SETUP	Setup / OPT /		
eq	EQ	EQ SUBTITLE	Subtitle / EQ		
radio	Radio	PROGRAM TV/RADIO	TV/Radio /		
snooze/dimmer	Snooze/dimmer	OK	OK		

https://alle-fernbedienungen.de/en/IHOME/1065806-94709-replacement-remote-control-for-IHOME-iH6-iH8.html