Original	Replacement
Theatre	PC FAV MARKER — Fav / Marker / PC
One-Touch Play	SHIFT + SLOW ▶ — Shift + Play /
Power	Power
Sleep	TIMER SLEEP — Sleep / Timer
Night	GOTO TEXT — Text / Goto
Dynamic Bass	SURROUND ⏏ — Eject / Surround
TV	SHIFT + TV 1 — Shift + 1
TV	PROGRAM TV/RADIO — TV/Radio /
1	TV 1 — 1
2	DVD 2 — 2
3	CD - STB 3 — 3
4	VIDEO 4 — 4
5	TAPE 5 — 5
6	TUNER 6 — 6
7	AUX - HDD 7 — 7
8	USB 8 — 8
9	BLUETOOTH 9 — 9

Original	Replacement
Clear	CLEAR EXIT CANCEL — Exit / Cancel / Clear
0	HDMI - SAT 0 — 0
Time	SHIFT + TIMER SLEEP — Shift + Sleep / Timer
Audio	LANG I/II AUDIO — Audio / Lang I/II
Subtitles / D.Tuning	EQ SUBTITLE — Subtitle / EQ
Angle	SHIFT + ANGLE INFO — Shift + Info / Angle
System Menu	SHIFT + HOME MENU — Shift + Menu /
Red	NETFLIX SEARCH — Red / Netflix / Search
Green	APP REPEAT — Green / APP / Repeat
Yellow	YouTube REPEAT A-B — Yellow / YouTube / Repeat
Blue	Prime Video RANDOM — Blue / Prime Video / Random
Top Menu	TOP MENU D.MENU — D.Menu / Top
Display	MEDIA DISPLAY — Display / Media
Pop Up / Menu	HOME MENU — Menu / Home
Up	Up
Left	Left
Enter	OK — OK

Original	Replacement	Original	Replacement
Right	Right	Mute	Mute / Dimmer
Return	Back / Return	Vol+	Vol+
Down	Down	Vol-	Vol-
Options	Setup / OPT /	Display	Info / Angle
Home	Smart / List		
Function	AV / Input / RDS		
Sound Mode	Sound / Title		
I<< / Preset-	I<< / Preset-		
<- Replay	CH- / Page-		
-> Advance	CH+ / Page+		
>>I / Preset+	>>I / Preset+		
<< / Tuning-	<< / Tune-		
Play	Play / Slow		
>> / Tuning+	>> / Tune+		
Scene Search	+ Shift + Red / Netflix /		
Pause	Pause / Step / Freeze		
Stop	Stop / Hold		

Original		Replacement	
I/⏻	Power	⏻	Power
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD - STB 3	3
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
7	7	AUX - HDD 7	7
8	8	USB 8	8
9	9	BLUETOOTH 9	9
CLEAR	Text	GOTO TEXT	Text / Goto
0	0	HDMI - SAT 0	0
-/-- TIME	-/--	SHIFT + -/-- GUIDE EPG	Shift + Guide / EPG / -/--
DIGITAL	Digital	LIST SMART	Smart / List
ANALOG D.TUNING	Analog	MEDIA DISPLAY	Display / Media
TOP MENU	Guide	-/-- GUIDE EPG	Guide / EPG / -/--
POP UP/MENU	Home / Menu	HOME MENU	Menu / Home

Original		Replacement	
OPTIONS TOOLS	Tools	OPT-TOOLS SETUP	Setup / OPT /
🔇	Muting	DIMMER MUTE	Mute / Dimmer
⊿ +	Volume+	+ VOL	Vol+
PROG +	Prog+	+ CH PAGE	CH+ / Page+
⊕	Source	RDS AV INPUT	AV / Input / RDS
−	Volume-	VOL −	Vol-
−	Prog-	CH PAGE −	CH- / Page-
DISPLAY	[i+]	ANGLE INFO	Info / Angle