Original		Replacement	
	POWER		Power
TV/R	TV/R	PROGRAM TV/ RADIO	TV/Radio /
	MUTE	DIMMER MUTE	Mute / Dimmer
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD - STB 3	3
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
7	7	AUX - HDD 7	7
8	8	USB 8	8
9	9	BLUETOOTH 9	9
SAT	SAT	SHIFT + HDMI - SAT 0	Shift + 0
SAT	SAT	LIST SMART	Smart / List
0	0	HDMI - SAT 0	0
PAUSE	PAUSE	STEP - FREEZE ⏸	Pause / Step / Freeze
EPG	EPG	-/-- GUIDE EPG	Guide / EPG / -/--

Original		Replacement	
EPG	RED	NETFLIX SEARCH	Red / Netflix / Search
AUDIO	GREEN	APP REPEAT	Green / APP / Repeat
AUDIO	AUDIO	LANG I/II AUDIO	Audio / Lang I/II
SUB	YELLOW	YouTube REPEAT A-B	Yellow / YouTube / Repeat
MENU	MENU	HOME MENU	Menu / Home
ZOOM	ZOOM	SIZE ZOOM	Zoom / Size
ZOOM	BLUE	Prime Video RANDOM	Blue / Prime Video / Random
EXIT	EXIT	CLEAR EXIT CANCEL	Exit / Cancel / Clear
V◀	LEFT	◀	Left
V◀	VOL -	VOL −	Vol-
CH▲	UP	▲	Up
CH▲	CH+	+ CH PAGE	CH+ / Page+
OK	OK	OK	OK
V▶	RIGHT	▶	Right
V▶	VOL +	+ VOL	Vol+
CH▼	CH-	CH PAGE −	CH- / Page-
CH▼	DOWN	▼	Down

Original		Replacement		Original	Replacement
PGUP	PG UP	SHIFT + CH PAGE +	Shift + CH+ /		
PGDN	PG DN	SHIFT + CH PAGE −	Shift + CH- /		
TXT	TXT	GOTO TEXT	Text / Goto		
FAV	FAV	PC FAV MARKER	Fav / Marker / PC		
RECALL	RECALL	RETURN BACK	Back / Return		
INFO	INFO	ANGLE INFO	Info / Angle		

Original		Replacement	
	Power		Power
TV/R	Tv/R	PROGRAM TV/RADIO	TV/Radio /
	Mute	DIMMER MUTE	Mute / Dimmer
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD - STB 3	3
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
7	7	AUX - HDD 7	7
8	8	USB 8	8
9	9	BLUETOOTH 9	9
SAT	SAT	SHIFT + HDMI - SAT 0	Shift + 0
0	0	HDMI - SAT 0	0
PAUSE	Pause	STEP - FREEZE ⏸	Pause / Step / Freeze
EPG	Red	NETFLIX SEARCH	Red / Netflix / Search
EPG	EPG	-/-- GUIDE EPG	Guide / EPG / -/--

Original		Replacement	
AUDIO	Green	APP REPEAT	Green / APP / Repeat
AUDIO	Audio	LANG I/II AUDIO	Audio / Lang I/II
SUB	Yellow	YouTube REPEAT A-B	Yellow / YouTube / Repeat
SUB	SUB	EQ SUBTITLE	Subtitle / EQ
MENU	Menu	HOME MENU	Menu / Home
ZOOM	Blue	Prime Video RANDOM	Blue / Prime Video / Random
ZOOM	Zoom	SIZE ZOOM	Zoom / Size
EXIT	Exit	CLEAR EXIT CANCEL	Exit / Cancel / Clear
V◀	Vol-	VOL −	Vol-
V◀	Left	◀	Left
CH▲	Up/CH+	▲	Up
V▶	Right	▶	Right
V▶	Vol+	+ VOL	Vol+
OK	OK	OK	OK
CH▼	Down/CH-	▼	Down
PGUP	PgUp	+ CH PAGE	CH+ / Page+
PGDN	PgDn	CH PAGE −	CH- / Page-

Original		Replacement	
TXT	TXT	GOTO TEXT	Text / Goto
FAV	FAV	PC FAV MARKER	Fav / Marker / PC
RECALL	Recall	RETURN BACK	Back / Return
INFO	Info	ANGLE INFO	Info / Angle

Original	Replacement