Original		Replacement		Original		Replacement	
	Power		Power		0		0
SLEEP	Sleep	TIMER SLEEP	Sleep / Timer	≧10	+10	-/-- GUIDE EPG	Guide / EPG / -/--
PLAY	Timer Play		Right	CD ▶/II	CD Play/Pause	SLOW	Play / Slow
OPEN/CLOSE	Open/Close	SURROUND	Eject / Surround	FM/AM	FM/AM	PROGRAM TV/RADIO	TV/Radio /
CLOCK/TIMER	Clock/Timer	SHIFT + TIMER SLEEP	Shift + Sleep / Timer		Stop	HOLD	Stop / Hold
1	1	TV 1	1	MUSIC PORT	Music Port	LIST SMART	Smart / List
2	2	DVD 2	2	VOL –	Vol -	VOL –	Vol -
3	3	CD-STB 3	3	+ VOL	Vol +	+ VOL	Vol +
PGM -AUTO PRESET	PGM-Auto	HOME MENU	Menu / Home	ALB	< Album	TUNE-	<< / Tune-
4	4	VIDEO 4	4	ALBUM	Album >	TUNE+	>> / Tune+
5	5	TAPE 5	5	∨	I<<Down	PRESET-	I<< / Preset-
6	6	TUNER 6	6	∧	>>I / Up	PRESET+	>>I / Preset+
CLEAR	Clear	CLEAR EXIT CANCEL	Exit / Cancel / Clear	ENTER	Enter	OK	OK
7	7	AUX-HDD 7	7	PRESET EQ	Preset EQ	EQ SUBTITLE	Subtitle / EQ
8	8	USB 8	8	SURROUND	Surround	SHIFT + SURROUND	Shift + Eject / Surround
9	9	BLUETOOTH 9	9	PLAY MODE	Play Mode	OPT-TOOLS SETUP	Setup / OPT /
DEL	Del	SHIFT + CLEAR EXIT CANCEL	Shift + Exit / Cancel / Clear	REMASTER	Remaster	TOP MENU D.MENU	D.Menu / Top Menu

Original		Replacement		Original	Replacement
D.BASS	D. Bass	TITLE SOUND	Sound / Title		
DISPLAY	Display	MEDIA DISPLAY	Display / Media		
REPEAT	Repeat	APP REPEAT	Green / APP / Repeat		