Original		Replacement	
	Power		Power
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD - STB 3	3
☼+	☼+	PRESET+ ⏭	>>I / Preset+
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
-☼	-☼	PRESET- ⏮	I<< / Preset-
7	7	AUX - HDD 7	7
8	8	USB 8	8
9	9	BLUETOOTH 9	9
O+	O+	TUNE+ ⏩	>> / Tune+
-O	-O	TUNE- ⏪	<< / Tune-
P/C ATS	0/AV	RDS AV INPUT	AV / Input / RDS
P/C ATS	0/AV	HDMI - SAT 0	0
0 AV	P/C-ATS	MEDIA DISPLAY	Display / Media

Original		Replacement	
i	i	ANGLE INFO	Info / Angle
	TXT	GOTO TEXT	Text / Goto
AUX	AUX	SHIFT + AUX - HDD 7	Shift + 7
R	Blue / R	Prime Video RANDOM	Blue / Prime Video / Random
P+	Up		Up
P+	P+	CH PAGE +	CH+ / Page+
	Right		Right
	Vol +	VOL +	Vol +
	Yellow	YouTube REPEAT A-B	Yellow / YouTube / Repeat
OK	OK	OK	OK
	Green/Timer	TIMER SLEEP	Sleep / Timer
	Green/Timer	APP REPEAT	Green / APP / Repeat
	Left		Left
	Vol -	VOL −	Vol -
P−	Down		Down
P−	P-	CH PAGE −	CH- / Page-
	Red	NETFLIX SEARCH	Red / Netflix / Search

Original	Replacement	Original	Replacement
Audio / Mute	Mute / Dimmer		
Audio / Mute	Audio / Lang I/II		

Original		Replacement		Original		Replacement	
	Power		Power				
1	<		Left				
2	>		Right				
+	Play	SLOW	Play / Slow				
−	Pause	STEP-FREEZE	Pause / Step / Freeze				
7	<<	TUNE-	<< / Tune-				
8	>>	TUNE+	>> / Tune+				
+	Stop	HOLD	Stop / Hold				
−	Rec	REC MODE	Rec / Rec Mode				
P+	P+	CH PAGE +	CH+ / Page+				
P-	P-	CH PAGE −	CH- / Page-				

Original	Replacement	Original	Replacement
Power	Power	i	Info / Angle
1	1	TXT	Text / Goto
2	2	AUX	Shift + 7
3	3	Blue / R	Blue / Prime Video / Random
☼+	>>I / Preset+	P+	CH+ / Page+
4	4	Up	Up
5	5	Right	Right
6	6	Vol +	Vol +
- ☼	I << / Preset-	Yellow	Yellow / YouTube / Repeat
7	7	OK	OK
8	8	Green/Timer	Green / APP / Repeat
9	9	Green/Timer	Sleep / Timer
O+	>> / Tune+	Left	Left
- O	<< / Tune-	Vol -	Vol -
0/ AV	AV / Input / RDS	P-	CH- / Page-
0/ AV	0	Down	Down
P/C- ATS	Display / Media	Red	Red / Netflix / Search

Original	Replacement	Original	Replacement
Audio / Mute	Mute / Dimmer		
Audio / Mute	Audio / Lang I/II		