Mandis shop

WL-61

Original		Replacement	
START /STOP	Start/Stop		Power
W	Zoom W	CH PAGE +	CH+ / Page+
T	Zoom T	CH PAGE −	CH- / Page-
	Left		Left
	Up		Up
	Right		Right
	Down		Down
PLAY	Play	SLOW ▶	Play / Slow
STOP	Stop	HOLD ■	Stop / Hold
EXECUTE	Execute	OK	OK
REW/	<</Rew	TUNE- ◀◀	<< / Tune-
FF/	>>/FF	TUNE+ ▶▶	>> / Tune+
COUNTER RESET	Counter Reset	CLEAR EXIT CANCEL	Exit / Cancel / Clear
PAUSE	Pause	STEP-FREEZE ⏸	Pause / Step / Freeze
ON SCREEN	On Screen	MEDIA DISPLAY	Display / Media
TAPE RETURN	Tape Return	RETURN BACK	Back / Return

https://alle-fernbedienungen.de/en/Canon/1067054-79814-replacement-remote-control-for-Canon-WL-61.html