Mandis shop

Sony RM-AMU171

Original	Replacement	Original	Replacement
Power	Power	Up/Folder+	Up
Play	Play / Slow	Left	Left
Pause	Pause / Step / Freeze	OK	OK
Stop	Stop / Hold	Right	Right
<<	<< / Tune-	Clear	Exit / Cancel / Clear
>>	>> / Tune+	Down/Folder-	Down
I<</Tune-	I<< / Preset-	Return	Back / Return
>>I/Tune+	>>I / Preset+	Vol+	Vol+
Bass Boost	Sound / Title	Play Mode	Smart / List
Audio In	Audio / Lang I/II	Bass+	CH+ / Page+
Sleep	Sleep / Timer	Vol-	Vol-
FM Mode	TV/Radio /	Display	Display / Media
Options	D.Menu / Top	Bass-	CH- / Page-
☼	Setup / OPT /	CD	3
Tuning Mode	Text / Goto	Tuner	6
Tuner Memory	AV / Input / RDS	USB	8
Timer Menu	Menu / Home	Bluetooth	9

https://alle-fernbedienungen.de/en/Sony/1067783-65921-replacement-remote-control-for-Sony-RM-AMU171-149229711.html

Original	Replacement	Original	Replacement
REPEAT Repeat	APP REPEAT Green / APP / Repeat		
+ TREBLE Treble+	SHIFT + ▲ Shift + Up		
TREBLE − Treble-	SHIFT + ▼ Shift + Down		