Original		Replacement	
POWER	Power		Power
AMP POWER	Power AMP	SHIFT +	Shift + Power
CD	CD	A	Red
RECORDER	Recorder	B	Green
NETWORK	Network	C	Yellow
PHONO	Phono	D	Blue
AUX	AUX	HOME SMART	Smart
TUNER	Tuner	APP MEDIA	Media
1	Internet Radio Preset 1	SHIFT + 1	Shift + 1
2	Internet Radio Preset 2	SHIFT + 2	Shift + 2
3	Internet Radio Preset 3	SHIFT + 3	Shift + 3
►/II	Play	PLAY MODE ►	Play
►/II	Pause	II	Pause
I<<	I<<	I<<	I<<
>>I	>>I	>>I	>>I
■	Stop	■	Stop
<<	<<	<<	<<

Original		Replacement	
►►	>>	►►	>>
+ PRESET	Preset+	+ CH	Ch +
PRESET −	Preset-	CH −	Ch -
FAVORITE PURE DIRECT	Pure Direct/Favorite	FAV PRE-CH	Pre Ch
VOLUME ▲	Vol +	+ VOL	Vol +
VOLUME ▼	Vol -	VOL −	Vol -
MUTE	Mute	MUTE	Mute
INFO	Info	DISPLAY INFO	Info
MODE	Mode	PICTURE FORMAT	Format
SOURCE	Source	TIMER AV	AV
MENU	Menu	TOP MENU MENU	Menu
▲	Up	▲	Up
▼	Down	▼	Down
◄	Right	►	Right
►	Left	◄	Left
ENTER	Enter	OK	Ok
1	1	1	1

Original		Replacement		Original	Replacement
2 ABC	2	2	2		
3 DEF	3	3	3		
4 GHI	4	4	4		
5 JKL	5	5	5		
6 MNO	6	6	6		
7 PQRS	7	7	7		
8 TUV	8	8	8		
9 WXYZ	9	9	9		
0	0	0	0		
+10	+10	-/-- GUIDE	Guide		
CLEAR	Clear	CLEAR EXIT	Exit		
RANDOM	Random	SETTINGS OPT	Options		
REPEAT	Repeat	REPEAT TEXT	Text		
PROGRAM SEARCH	Search/ Program	PROG SLEEP	Sleep		
DIMMER	Dimmer	SOUND DUAL	Dual		

Original		Replacement	
POWER	Power		Power
AMP POWER	Power AMP	SHIFT +	Shift + Power
CD	CD	A	Red
RECORDER	Recorder	B	Green
NETWORK	Network	C	Yellow
PHONO	Phono	D	Blue
AUX	AUX	HOME SMART	Smart
TUNER	Tuner	APP MEDIA	Media
►/II	Play	PLAY MODE ►	Play
►/II	Pause	II	Pause
I<<	I<<	I<<	I<<
>>I	>>I	>>I	>>I
■	Stop	■	Stop
<<	<<	<<	<<
>>	>>	>>	>>
PRESET +	Preset +	CH +	Ch +
PRESET −	Preset -	CH −	Ch -

Original		Replacement	
FAVORITE PURE DIRECT	Pure Direct/Favorite	FAV PRE-CH	Pre Ch
VOLUME ▲	Vol +	VOL +	Vol +
VOLUME ▼	Vol -	VOL −	Vol -
MUTE	Mute	MUTE	Mute
INFO	Info	DISPLAY INFO	Info
MODE	Mode	PICTURE FORMAT	Format
SOURCE	Source	TIMER AV	AV
MENU	Menu	TOP MENU MENU	Menu
▲	Up	▲	Up
▼	Down	▼	Down
►	Right	►	Right
◄	Left	◄	Left
ENTER	Enter	OK	Ok
1 ./	1	1	1
2 ABC	2	2	2
3 DEF	3	3	3
4 GHI	4	4	4

Original		Replacement		Original		Replacement	
5 JKL	5	5	5				
6 MNO	6	6	6				
7 PQRS	7	7	7				
8 TUV	8	8	8				
9 WXYZ	9	9	9				
0	0	0	0				
+10	+10	GUIDE	Guide				
CLEAR	Clear	CLEAR EXIT	Exit				
RANDOM	Random	SETTINGS OPT	Options				
REPEAT	Repeat	REPEAT TEXT	Text				
PROGRAM SEARCH	Search/ Program	PROG SLEEP	Sleep				
DIMMER	Dimmer	SOUND DUAL	Dual				