Original		Replacement	
POWER	Power		Power
SLEEP	Sleep	PROG SLEEP	Sleep
CBL/SAT	CBL/SAT	1	1
MEDIA PLAYER	Media Player	2	2
Blu-ray	Blu-ray	3	3
GAME	Game	4	4
AUX1	AUX1	5	5
AUX2	AUX2	6	6
PHONO	Phono	7	7
TV AUDIO	TV Audio	8	8
TUNER	Tuner	9	9
USB	USB	-/-- GUIDE	Guide
Bluetooth	Bluetooth	0	0
INTERNET RADIO	Internet Radio	FAV PRE-CH	Pre Ch
	Micro	HOME SMART	Smart
CH / PAGE	CH/Page Up	+ CH	Ch +
CH / PAGE	CH/Page Down	CH –	Ch -

Original		Replacement	
ECO	Eco	ECO 3D	3D
VOLUME	Volume Up	+ VOL	Vol +
VOLUME	Volume Down	VOL –	Vol -
MUTE	Mute	MUTE	Mute
INFO	Info	DISPLAY INFO	Info
OPTION	Option	SETTINGS OPT	Options
BACK	Back	RETURN BACK	Back
SETUP	Setup	TOP MENU MENU	Menu
►/II	Play	PLAY MODE ►	Play
▲	Up	▲	Up
▼	Down	▼	Down
►	Right	►	Right
◄	Left	◄	Left
ENTER	Enter	OK	Ok
TUNE – I<<	I<<</Tune-	I<<	I<<
►/II	Pause	II	Pause
TUNE + >>I	>>I/Tune+	>>I	>>I

Original		Replacement	
1	Quick Select 1	E-MANUAL D.MENU	D. Menu
2	Qucki Select 2	REPEAT TEXT	Text
4	Quick Select 4	TIMER AV	AV
3	Quick Select 3	ZOOM ⏏	Eject
MOVIE	Green/Movie	A	Red
MUSIC	Red/Music	B	Green
GAME	Blue/Game	D	Blue
PURE	Yellow/Pure	C	Yellow

Original	Replacement

Original		Replacement	
POWER	Power		Power
SLEEP	Sleep	PROG SLEEP	Sleep
CBL/SAT	CBL/SAT	1	1
MEDIA PLAYER	Media Player	2	2
Blu-ray	Blu-ray	3	3
GAME	Game	4	4
AUX1	AUX1	5	5
AUX2	AUX2	6	6
PHONO	Phono	7	7
TV AUDIO	TV Audio	8	8
TUNER	Tuner	9	9
USB	USB	-/-- GUIDE	Guide
Bluetooth	Bluetooth	0	0
INTERNET RADIO	Internet Radio	FAV PRE-CH	Pre Ch
	Micro	HOME SMART	Smart
CH / PAGE	CH/Page Up	+ CH	Ch +
CH / PAGE	CH/Page Down	CH –	Ch -

Original		Replacement	
VOLUME	Volume Up	+ VOL	Vol +
VOLUME	Volume Down	VOL –	Vol -
MUTE	Mute	MUTE	Mute
	Up		Up
	Down		Down
	Right		Right
	Left		Left
ENTER	Enter	OK	Ok
BACK	Back	RETURN BACK	Back
TUNE –	I<<</Tune-		I<<
	Play	PLAY MODE	Play
	Pause		Pause
TUNE +	>>I/Tune+		>>I
1	Quick Select 1	E-MANUAL D.MENU	D. Menu
2	Quick Select 2	REPEAT TEXT	Text
3	Quick Select 3	ZOOM	Eject
4	Quick Select 4	TIMER AV	AV