Original		Replacement	
OFF	Off	SHIFT +	Shift + Power
ON/SOURCE	On/Source		Power
OFF	Main OFF	SHIFT +	REC MODE Shift + Rec / Rec Mode
ON	Main ON	REC MODE	Rec / Rec Mode
SHIFT	Shift	LIST SMART	Smart / List
CHANNEL −	Channel -	CH PAGE −	CH- / Page-
CHANNEL +	Channel +	+ CH PAGE	CH+ / Page+
QUICK SELECT 2	Quick Select 2	SHIFT +	DVD 2 Shift + 2
3	Quick Select 3	SHIFT +	CD-STB 3 Shift + 3
PHONO 1	1/PHONO	TV 1	1
CD 2	2/CD	DVD 2	2
TUNER 3	3/Tuner	CD-STB 3	3
1	Quick Select 1	SHIFT +	TV 1 Shift + 1
DVD/HDP	DVD/HDP	Prime Video RANDOM	Blue / Prime Video / Random
TV/CBL	TV/CBL	PROGRAM TV/RADIO	TV/Radio /
VCR	VCR	SHIFT +	VIDEO 4 Shift + 4
DVD/HDP 4	4/DVD/HDP	VIDEO 4	4

Original		Replacement	
TV/CBL 5	5/TV/CBL	TAPE 5	5
VCR 6	6/VCR	TUNER 6	6
	Stop	HOLD	Stop / Hold
DVR 7	7/DVR	AUX-HDD 7	7
V.AUX 8	8/V.AUX	USB 8	8
9	9	BLUETOOTH 9	9
	Play	SLOW	Play / Slow
AUX	AUX	SHIFT +	AUX-HDD 7 Shift + 7
iPod 0	0/iPod	HDMI-SAT 0	0
DTU +10	+10/DTU	-/-- GUIDE EPG	Guide / EPG / -/--
SKIP+/FAVORITE	Skip+/Favorite	PC FAV MARKER	Fav / Marker / PC
CINEMA	Cinema	OPT-TOOLS SETUP	Setup / OPT /
MUSIC	Music	TITLE SOUND	Sound / Title
STD	STD	GOTO TEXT	Text / Goto
A/B	Pause/A/B	STEP-FREEZE	Pause / Step / Freeze
TUNING/TV VOL	Tuning+/Tv	SHIFT +	+ VOL Shift + Vol +
	>>	TUNE+	>> / Tune+

Original	Replacement
Vol +	Vol +
Tuning-/Tv Vol	Shift + Vol -
D/ST	Picture / Format
Pure	Zoom / Size
SIMU	Red / Netflix / Search
<<	<< / Tune-
Mode/DVD	Shift + D.Menu / Top Menu
A.Menu/Setup	D.Menu / Top
Input/Audio	AV / Input / RDS
>>I/CH+	>>I / Preset+
Vol -	Vol -
I<<CH-	I<< / Preset-
Band/Pic.Adj	Green / APP / Repeat
Muting	Mute / Dimmer
Memory/Subtitl	Subtitle / EQ
Test/Display	Shift + Display / Media
Return	Shift + Back / Return

Original	Replacement
V.Select/Setup	Shift + Menu /
Up	Up
Night/Audio	Audio / Lang I/II
Left	Left
CH Sel/Enter	OK
Right	Right
Display	Display / Media
Down	Down
Status/Return	Back / Return
Dimmer/Menu/Gui	Menu / Home

Original	Replacement	Original	Replacement
Off	SHIFT + Power	Skip+/Favorite	PC FAV MARKER: Fav / Marker / PC
On/Source	Power	Pause/A/B	STEP-FREEZE: Pause / Step / Freeze
Channel -	CH PAGE -: CH- / Page-	Tuning/Tv Vol +	SHIFT + VOL +: Shift + Vol +
Channel +	CH PAGE +: CH+ / Page+	>>	TUNE+: >> / Tune+
1	TV 1: 1	Vol +	VOL +: Vol +
2	DVD 2: 2	Tuning/Tv Vol -	SHIFT + VOL -: Shift + Vol -
3	CD-STB 3: 3	<<	TUNE-: << / Tune-
4	VIDEO 4: 4	>>I	PRESET+: >>I / Preset+
5	TAPE 5: 5	Vol -	VOL -: Vol -
6	TUNER 6: 6	I <<	PRESET-: I << / Preset-
Stop	HOLD ■: Stop / Hold	Band/Pic. Adj	APP REPEAT: Green / APP / Repeat
7	AUX-HDD 7: 7	Muting	DIMMER MUTE: Mute / Dimmer
8	USB 8: 8	Memory/Subtitl	EQ SUBTITLE: Subtitle / EQ
9	BLUETOOTH 9: 9	V. Select/Setup	SHIFT + MEDIA DISPLAY: Shift + Display / Media
Play	SLOW ▶: Play / Slow	Up	Up
0	HDMI-SAT 0: 0	Night/Audio	LANG I/II AUDIO: Audio / Lang I/II
+10	-/-- GUIDE EPG: Guide / EPG / -/--	Left	Left

Original		Replacement	
CH SEL ENTER	Enter	OK	OK
	Right		Right
DISPLAY	Display	MEDIA DISPLAY	Display / Media
	Down		Down
STATUS RETURN	Status/Return	RETURN BACK	Back / Return
DIMMER MENU/GUIDE	Dimmer/Menu/Gui	HOME MENU	Menu / Home

Original	Replacement

Original	Replacement
Off	Shift + Power
On/Source	Power
Stop	Stop / Hold
Play	Play / Slow
Skip+/Favorite	Fav / Marker / PC
Pause/A/B	Pause / Step / Freeze
>>	>> / Tune+
Vol +	Vol +
<<	<< / Tune-
>>I	>>I / Preset+
Vol -	Vol -
I <<	I << / Preset-
Muting	Mute / Dimmer
Up	Up
Left	Left
Enter	OK
Right	Right

Original	Replacement
Down	Down