# Mandis shop

TQL32R4PR001

| Original | | Replacement | |
|---|---|---|---|
| POWER | Power | | Power |
| TV/RADIO | Tv/Radio | PROGRAM TV/RADIO | TV/Radio / |
| | Red | NETFLIX SEARCH | Red / Netflix / Search |
| | Green | APP REPEAT | Green / APP / Repeat |
| | Yellow | YouTube REPEAT A-B | Yellow / YouTube / Repeat |
| | Blue | Prime Video RANDOM | Blue / Prime Video / Random |
| FAV | FAV | PC FAV MARKER | Fav / Marker / PC |
| TEXT | Text | GOTO TEXT | Text / Goto |
| HOLD | Hold | SHIFT + HOLD | Shift + Stop / |
| TVG | TVG | -/-- GUIDE EPG | Guide / EPG / -/-- |
| SUBTITLE | Subtitle | EQ SUBTITLE | Subtitle / EQ |
| SIZE | Size | SIZE ZOOM | Zoom / Size |
| ASPECT | Aspect | SHIFT + FORMAT PICTURE | Shift + Picture / Format |
| MEDIA | Media | LIST SMART | Smart / List |
| SUBPAGE | Subpage | SURROUND | Eject / Surround |
| | Play | SLOW | Play / Slow |
| | Pause | STEP-FREEZE | Pause / Step / Freeze |

| Original | | Replacement | |
|---|---|---|---|
| | << | TUNE- | << / Tune- |
| | >> | TUNE+ | >> / Tune+ |
| | Rec | REC MODE | Rec / Rec Mode |
| | Stop | HOLD | Stop / Hold |
| | I<< | PRESET- | I<< / Preset- |
| MENU | Sleep | TIMER SLEEP | Sleep / Timer |
| INDEX | >>I / Index | PRESET+ | >>I / Preset+ |
| AUDIO | Audio | LANG I/II AUDIO | Audio / Lang I/II |
| SLEEP | Menu | HOME MENU | Menu / Home |
| EXIT | Exit | CLEAR EXIT CANCEL | Exit / Cancel / Clear |
| | Up | | Up |
| | Down | | Down |
| | Right | | Right |
| | Left | | Left |
| OK | OK | OK | OK |
| + VOL | Vol + | + VOL | Vol + |
| VOL − | Vol - | VOL − | Vol - |

| Original | | Replacement | | Original | | Replacement | |
|---|---|---|---|---|---|---|---|
| MUTE | Mute | DIMMER MUTE | Mute / Dimmer | P-MODE | P. Mode | FORMAT PICTURE | Picture / Format |
| DISPLAY | Display | MEDIA DISPLAY | Display / Media | S-MODE | S. Mode | TITLE SOUND | Sound / Title |
| + CH | CH+ | + CH PAGE | CH+ / Page+ | | | | |
| CH − | CH- | CH PAGE − | CH- / Page- | | | | |
| 1 | 1 | TV 1 | 1 | | | | |
| 2 | 2 | DVD 2 | 2 | | | | |
| 3 | 3 | CD - STB 3 | 3 | | | | |
| 4 | 4 | VIDEO 4 | 4 | | | | |
| 5 | 5 | TAPE 5 | 5 | | | | |
| 6 | 6 | TUNER 6 | 6 | | | | |
| 7 | 7 | AUX - HDD 7 | 7 | | | | |
| 8 | 8 | USB 8 | 8 | | | | |
| 9 | 9 | BLUETOOTH 9 | 9 | | | | |
| 0 | 0 | HDMI - SAT 0 | 0 | | | | |
| -/-- | -/-- | SHIFT + -/-- GUIDE EPG | Shift + Guide / EPG / -/-- | | | | |
| Recall | Recall | RETURN BACK | Back / Return | | | | |
| SOURCE | Source | RDS AV INPUT | AV / Input / RDS | | | | |