Original		Replacement	
STANDBY	Power		Power
DTV/VCR	DTV/VCR	RDS AV INPUT	AV / Input / RDS
MUTE	Mute	DIMMER MUTE	Mute / Dimmer
INFO	Info	ANGLE INFO	Info / Angle
PLAY/PAUSE	Play	SLOW	Play / Slow
PLAY/PAUSE	Pause	STEP-FREEZE	Pause / Step / Freeze
MENU	Menu	HOME MENU	Menu / Home
EPG	EPG	-/-- GUIDE EPG	Guide / EPG / -/--
EXIT	Exit	CLEAR EXIT CANCEL	Exit / Cancel / Clear
	Up		Up
	CH+	CH+ CH PAGE	CH+ / Page+
	Left		Left
	Vol -	VOL -	Vol -
OK	OK	OK	OK
	Right		Right
	Vol +	+ VOL	Vol +
REC LIST	Rec List	LIST SMART	Smart / List

Original		Replacement	
	CH-	CH PAGE -	CH- / Page-
	Down		Down
FAVORITE	Favorite	PC FAV MARKER	Fav / Marker / PC
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD-STB 3	3
GAME	Game	MEDIA DISPLAY	Display / Media
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
RECALL	Recall	RETURN BACK	Back / Return
7	7	AUX-HDD 7	7
8	8	USB 8	8
9	9	BLUETOOTH 9	9
0	0	HDMI-SAT 0	0
TV/RADIO	Tv/Radio	PROGRAM TV/RADIO	TV/Radio /
AUDIO	Audio	LANG I/II AUDIO	Audio / Lang I/II

Original		Replacement		Original	Replacement
SUBTITLE	Subtitle	EQ SUBTITLE	Subtitle / EQ		
TEXT	Text	GOTO TEXT	Text / Goto		
	Red	NETFLIX SEARCH	Red / Netflix / Search		
	Green	APP REPEAT	Green / APP / Repeat		
	Yellow	YouTube REPEAT A-B	Yellow / YouTube / Repeat		
	Blue	Prime Video RANDOM	Blue / Prime Video / Random		
RECORD	Record	REC MODE	Rec / Rec Mode		
STOP	Stop	HOLD	Stop / Hold		
REV	<<	TUNE-	<< / Tune-		
FWD	>>	TUNE+	>> / Tune+		