Original		Replacement	
DVD/TV	DVD/TV	PROGRAM TV/RADIO	TV/Radio /
Power	Power	Power	Power
i	i	ANGLE INFO	Info / Angle
AV	AV	RDS AV INPUT	AV / Input / RDS
Red	Red	NETFLIX SEARCH	Red / Netflix / Search
Green	Green	APP REPEAT	Green / APP / Repeat
Yellow	Yellow	YouTube REPEAT A-B	Yellow / YouTube / Repeat
Blue	Blue	Prime Video RANDOM	Blue / Prime Video / Random
P+	P+	CH PAGE +	CH+ / Page+
P+	Up		
V-	Vol -	VOL −	
V-	Left		
V+	Vol +	+ VOL	
V+	Right		
P-	CH- / Page-	CH PAGE −	
P-	Down		
MUTE	Mute	DIMMER MUTE	Mute / Dimmer

Original		Replacement	
TV	TV	SIZE ZOOM	Zoom / Size
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD-STB 3	3
Recall	Recall	RETURN BACK	Back / Return
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
16:9	16:9	FORMAT PICTURE	Picture / Format
7	7	AUX-HDD 7	7
8	8	USB 8	8
9	9	BLUETOOTH 9	9
PP	PP	PC FAV MARKER	Fav / Marker / PC
S/M/D	S/M/D	-/-- GUIDE EPG	Guide / EPG / -/--
0	0	HDMI-SAT 0	0
MENU	Menu	HOME MENU	Menu / Home
EXIT	Exit	CLEAR EXIT CANCEL	Exit / Cancel / Clear

Original		Replacement	
TITLE	[=]	GOTO TEXT	Text / Goto
CLEAR	`/ =]	SHIFT + GOTO TEXT	Shift + Text /
ANGLE	[=o]	SLOW	Play / Slow
ZOOM	[=i]	STEP-FREEZE	Pause / Step / Freeze
DIGEST	[=+]	HOLD	Stop / Hold
P.M	[=♦]	REC MODE	Rec / Rec Mode
MARK	[=x]	TUNE-	<< / Tune-
A-B	[=?]	TUNE+	>> / Tune+

Original	Replacement

Original		Replacement	
	Power		Power
	1	TV 1	1
	2	DVD 2	2
	3	CD-STB 3	3
	4	VIDEO 4	4
	5	TAPE 5	5
	6	TUNER 6	6
	7	AUX-HDD 7	7
	8	USB 8	8
	9	BLUETOOTH 9	9
	0	HDMI-SAT 0	0
AUDIO	Audio	LANG I/II AUDIO	Audio / Lang I/II
SUB	SUB	EQ SUBTITLE	Subtitle / EQ
<	<	SHIFT +	Shift + Left
>	>	SHIFT +	Shift + Right
	Pause	STEP-FREEZE	Pause / Step / Freeze
	Open/Close	SURROUND	Eject / Surround

Original		Replacement	
	I <<	PRESET-	I << / Preset-
	Play	SLOW	Play / Slow
	>>I	PRESET+	>>I / Preset+
	<<	TUNE-	<< / Tune-
	Stop	HOLD	Stop / Hold
	>>	TUNE+	>> / Tune+
DISPLAY	Display	MEDIA DISPLAY	Display / Media
MENU	Menu	HOME MENU	Menu / Home
	Up		Up
SETUP	Setup	OPT-TOOLS SETUP	Setup / OPT /
3D	3D	SHIFT + CD-STB 3	Shift + 3
	Left		Left
ENTER	Enter	OK	OK
	Right		Right
SEARCH	Search	NETFLIX SEARCH	Red / Netflix / Search
RETURN	Return	RETURN BACK	Back / Return
	Down		Down

Original		Replacement		Original	Replacement
EXIT	Exit	CLEAR EXIT CANCEL	Exit / Cancel / Clear		
TITLE	Title	TITLE SOUND	Sound / Title		
CLEAR	Clear	SHIFT +	CLEAR EXIT CANCEL Shift + Exit / Cancel / Clear		
ANGLE	Angle	ANGLE INFO	Info / Angle		
ZOOM	Zoom	SIZE ZOOM	Zoom / Size		
DIGEST	Digest	Prime Video RANDOM	Blue / Prime Video / Random		
P.M	P.M	GOTO TEXT	Text / Goto		
MARK	Mark	PC FAV MARKER	Fav / Marker / PC		
A-B	A-B	YouTube REPEAT A-B	Yellow / YouTube / Repeat		