Original	Replacement	Original	Replacement
Power	Power	P+	CH+ / Page+
1	1	Up	Up
2	2	Vol -	Vol -
3	3	Left	Left
4	4	OK	OK
5	5	Vol +	Vol +
6	6	Right	Right
7	7	TXT/Menu	Menu / Home
8	8	TXT/Menu	Text / Goto
9	9	P-	CH- / Page-
0	0	Down	Down
?	Smart / List	TV-G/Top Menu	D.Menu / Top
[<>]/[...]	Setup / OPT /	Red/Picture/Re	Red / Netflix / Search
AV	AV / Input / RDS	Red/Picture/Re	Rec / Rec Mode
Mute	Mute / Dimmer	Green/Timer/Play	Green / APP / Repeat
i	Info / Angle	Green/Timer/Play	Sleep / Timer
PIP/Recall	Back / Return	Green/Timer/Play	Play / Slow

Original	Replacement	Original	Replacement
Yellow/ Pause	Yellow / YouTube / Repeat		
Yellow/ Pause	Pause / Step / Freeze		
Blue/ Audio/ Stop	Audio / Lang I/II		
Blue/ Audio/ Stop	Blue / Prime Video / Random		
Blue/ Audio/ Stop	Stop / Hold		
I◁/ Scan	I<< / Preset-		
▷I / PAP	>>I / Preset+		
<◁/ S	<< / Tune-		
<◁/ S	Sound / Title		
>▷/ P	>> / Tune+		
>▷/ P	Picture / Format		

Original	Replacement	Original	Replacement
Power	Power	P+	CH+ / Page+
1	1	Up	Up
2	2	Vol -	Vol -
3	3	Left	Left
4	4	OK	OK
5	5	Vol +	Vol +
6	6	Right	Right
7	7	TXT/Menu	Menu / Home
8	8	P-	CH- / Page-
9	9	Down	Down
0	0	TV-G/Top Menu	D.Menu / Top
?	Smart / List	Red/Picture/Re	Rec / Rec Mode
[<>]/[...]	Subtitle / EQ	Red/Picture/Re	Red / Netflix / Search
AV	AV / Input / RDS	Green/Timer/Play	Sleep / Timer
Mute	Mute / Dimmer	Green/Timer/Play	Play / Slow
i	Info / Angle	Green/Timer/Play	Green / APP / Repeat
PIP/Recall	Back / Return	Yellow/Pause	Yellow / YouTube / Repeat

Original		Replacement		Original		Replacement	
	Yellow/Pause	STEP-FREEZE	Pause / Step / Freeze				
	Blue/Audio/Stop	Prime Video RANDOM	Blue / Prime Video / Random				
	Blue/Audio/Stop	LANG I/II AUDIO	Audio / Lang I/II				
	Blue/Audio/Stop	HOLD	Stop / Hold				
SCAN	I◁/Scan	PRESET-	I<< / Preset-				
PAP	▷I / PAP	PRESET+	>>I / Preset+				
S	<◁/S	TUNE-	<< / Tune-				
P	>▷/P	TUNE+	>> / Tune+				

Original	Replacement	Original	Replacement
Power	Power	P+	CH+ / Page+
1	1	Up	Up
2	2	Vol -	Vol -
3	3	Left	Left
4	4	OK	OK
5	5	Vol +	Vol +
6	6	Right	Right
7	7	TXT/Menu	Menu / Home
8	8	P-	CH- / Page-
9	9	Down	Down
0	0	TV-G/Top Menu	D.Menu / Top
?	Smart / List	Red/Picture/Re	Red / Netflix / Search
[<>]/[...]	Subtitle / EQ	Red/Picture/Re	Rec / Rec Mode
AV	AV / Input / RDS	Green/Timer/Play	Sleep / Timer
Mute	Mute / Dimmer	Green/Timer/Play	Green / APP / Repeat
i	Info / Angle	Green/Timer/Play	Play / Slow
PIP / Recall	Back / Return	Yellow/Pause	Yellow / YouTube / Repeat

Original	Replacement	Original	Replacement
Yellow/Pause	STEP-FREEZE Pause / Step / Freeze		
Blue/Audio/Stop	Prime Video RANDOM Blue / Prime Video / Random		
Blue/Audio/Stop	LANG I/II AUDIO Audio / Lang I/II		
Blue/Audio/Stop	HOLD Stop / Hold		
I◁/Scan	PRESET- I<< / Preset-		
▷I/PAP	PRESET+ >>I / Preset+		
<<◁/S	TUNE- << / Tune-		
>>▷/P	TUNE+ >> / Tune+		