Original		Replacement	
	Power		Power
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	? / Audio		Audio / Lang I/II
	0		0
	Aspect / Subtitl		Zoom / Size
	Aspect / Subtitl		Subtitle / EQ
	PIP / Recall		Fav / Marker / PC
	AV		AV / Input / RDS
	Mute		Mute / Dimmer

Original		Replacement	
	i		Info / Angle
	Up / P+		Up
	Up / P+		CH+ / Page+
	Z / Return		Back / Return
	Left / Vol -		Left
	Left / Vol -		Vol -
	OK		OK
	Right / Vol +		Right
	Right / Vol +		Vol +
	TXT / Menu		Menu / Home
	TXT / Menu		Text / Goto
	Down / P-		Down
	Down / P-		CH- / Page-
	TV-G / Top		D.Menu / Top
	Red / Rec		Rec / Rec Mode
	Red / Rec		Red / Netflix / Search
	Green / Play		Play / Slow

Original	Replacement	Original	Replacement
Green / Play	Green / APP / Repeat		
Yellow / Pause	Yellow / YouTube / Repeat		
Yellow / Pause	Pause / Step / Freeze		
Blue / Stop	Blue / Prime Video / Random		
Blue / Stop	Stop / Hold		
Scan / I<	I<< / Preset-		
PAT / >I	>>I / Preset+		
S / <<	<< / Tune-		
P / >>	>> / Tune+		

Original		Replacement	
	Power		Power
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	? / Langs		Audio / Lang I/II
	0		0
	[<>]/[...]		Subtitle / EQ
	PIP / Repeat		Shift + Green / APP /
	AV		AV / Input / RDS
	Mute		Mute / Dimmer
	i		Info / Angle

Original		Replacement	
	P+		CH+ / Page+
	Up		Up
	Vol -		Vol -
	Left		Left
	OK		OK
	Vol +		Vol +
	Right		Right
	TXT/Menu		Menu / Home
	P-		CH- / Page-
	Down		Down
	TV-G/Top Menu		D.Menu / Top
	Red/Picture/Re		Red / Netflix / Search
	Red/Picture/Re		Picture / Format
	Green/Timer/Play		Green / APP / Repeat
	Green/Timer/Play		Play / Slow
	Green/Timer/Play		Sleep / Timer
	Yellow/Pause		Yellow / YouTube / Repeat

Original	Replacement	Original	Replacement
Yellow/Pause	Pause / Step / Freeze		
Blue/Audio/Stop	Sound / Title		
Blue/Audio/Stop	Stop / Hold		
Blue/Audio/Stop	Blue / Prime Video / Random		
I◁/Scan	I<< / Preset-		
>I / PAP	>>I / Preset+		
<<◁/S	<< / Tune-		
>>▷/P	>> / Tune+		

Original		Replacement	
	Power		Power
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	? / Langs		Audio / Lang I/II
	0		0
	[<>]/[. . .]		Zoom / Size
	[<>]/[. . .]		Subtitle / EQ
	PIP/Repeat		Shift + Green / APP /
	AV		AV / Input / RDS
	Mute		Mute / Dimmer

Original		Replacement	
	i		Info / Angle
	P+		CH+ / Page+
	Up		Up
	Vol -		Vol -
	Left		Left
	OK		OK
	Vol +		Vol +
	Right		Right
	TXT/Menu		Menu / Home
	P-		CH- / Page-
	Down		Down
	TV-G/Top Menu		D.Menu / Top
	Red/Picture/Re		Rec / Rec Mode
	Red/Picture/Re		Picture / Format
	Red/Picture/Re		Red / Netflix / Search
	Green/Timer>/Pla		Green / APP / Repeat
	Green/Timer>/Pla		Play / Slow

y

Original	Replacement	Original	Replacement
Green/Timer >/Pla	Sleep / Timer		
Yellow/Pause	Pause / Step / Freeze		
Yellow/Pause	Yellow / YouTube / Repeat		
Blue/Audio/Stop	Sound / Title		
Blue/Audio/Stop	Blue / Prime Video / Random		
Blue/Audio/Stop	Stop / Hold		
I</Scan	I<< / Preset-		
>I / PAP	>>I / Preset+		
<<</S	<< / Tune-		
>>/P	>> / Tune+		