Mandis shop

Hisense EN218A8H

Original	Replacement	Original	Replacement
Power	Power		
Mute	Mute / Dimmer		
Source	AV / Input / RDS		
Bluetooth	9		
Vol+	Vol+		
Vol-	Vol-		
>I	>>I / Preset+		
I<	I<< / Preset-		
Pair	OK		
Pause	Pause / Step / Freeze		
Play	Play / Slow		
EQ	Subtitle / EQ		
Surr	Audio / Lang I/II		
Dimmer+	Right		
Dimmer-	Left		
Bass	Up		
Treble	Down		

https://alle-fernbedienungen.de/en/Hisense/1064852-95364-replacement-remote-control-for-Hisense-EN218A8H.html