Original		Replacement	
TV DIRECT	TV Direct	LIST SMART	Smart / List
DVD	Power DVD	NETFLIX SEARCH	Red / Netflix / Search
VCR	Power VCR	APP REPEAT	Green / APP / Repeat
AUDIO	Power Audio		Power
STB	Power STB	YouTube REPEAT A-B	Yellow / YouTube / Repeat
TV	Power TV	Prime Video RANDOM	Blue / Prime Video / Random
DVD	DVD	DVD 2	2
VCR	VCR	VIDEO 4	4
TV	TV	TV 1	1
FM/AM	FM/AM	TUNER 6	6
TV/VIDEO	Tv/Video	TAPE 5	5
MUTING	Muting	DIMMER MUTE	Mute / Dimmer
CHANNEL +	Channel+	+ CH PAGE	CH+ / Page+
VOLUME +	Volume+	+ VOL	Vol+
—	Channel-	CH PAGE —	CH- / Page-
—	Volume-	VOL —	Vol-
ON SCREEN DISPLAY	Display/On Screen	MEDIA DISPLAY	Display / Media

Original		Replacement	
DIMMER	Dimmer	SHIFT + DIMMER MUTE	Shift + Mute / Dimmer
SLEEP	Sleep	TIMER SLEEP	Sleep / Timer
ANALOG/DIGITAL INPUT	Analog/Digital Input	RDS AV INPUT	AV / Input / RDS
SMART S SETUP	Smart S Setup	OPT-TOOLS SETUP	Setup / OPT /
BASS BOOST	Bass Boost	LANG I/II AUDIO	Audio / Lang I/II
TONE	C. Tone	EQ SUBTITLE	Subtitle / EQ
A.POSITION	A. Position	TOP MENU D.MENU	D.Menu / Top
TEST	Test Tone	GOTO TEXT	Text / Goto
EFFECT	Effect	ANGLE INFO	Info / Angle
DECODE	Decode	PROGRAM TV/RADIO	TV/Radio /
SURROUND	Surround	SURROUND ⏏	Eject / Surround
SUBWFR +	Subwfr+	▶	Right
CENTER +	Center+	▲	Up
L-SUR +	Surr L+	SHIFT + + VOL	Shift + Vol+
SURR-R +	Surr R+	SHIFT + + CH PAGE	Shift + CH+ /
—	Subwfr-	◀	Left
—	Center-	▼	Down

Original	Replacement	Original	Replacement
Surr L-	SHIFT + VOL – Shift + Vol-		
Surr R-	SHIFT + CH PAGE – Shift + CH- /		

Original	Replacement
Power Audio	Power
Power Tv	SHIFT + Power — Shift + Power
FM/AM	SURROUND — Eject / Surround
Tv Vol+	VOL + — Vol+
Channel+ TV	CH + PAGE — CH+ / Page+
Tv Vol-	VOL − — Vol-
Channel- TV	CH PAGE − — CH- / Page-
Tuning- FM/AM	TUNE- — << / Tune-
FM Mode FM/AM	LIST SMART — Smart / List
Tuning+ FM/AM	TUNE+ — >> / Tune+
Memory FM/AM	HOME MENU — Menu / Home
TA/News/Info	ANGLE INFO — Info / Angle
TA/News/Info	▲ — Up
PTY- FM/AM	◀ — Left
PTY+ FM/AM	▶ — Right
PTY Search	▼ — Down
PTY Search	NETFLIX SEARCH — Red / Netflix / Search

Original	Replacement
Display FM/AM	MEDIA DISPLAY — Display / Media
1 FM/AM	SHIFT + TV 1 — Shift + 1
1 TV	TV 1 — 1
2 FM/AM	SHIFT + DVD 2 — Shift + 2
2 TV	DVD 2 — 2
3 FM/AM	SHIFT + CD-STB 3 — Shift + 3
3 TV	CD-STB 3 — 3
4 FM/AM	SHIFT + VIDEO 4 — Shift + 4
4 TV	VIDEO 4 — 4
5 FM/AM	SHIFT + TAPE 5 — Shift + 5
5 TV	TAPE 5 — 5
6 FM/AM	SHIFT + TUNER 6 — Shift + 6
6 TV	TUNER 6 — 6
7 FM/AM	SHIFT + AUX-HDD 7 — Shift + 7
7 TV	AUX-HDD 7 — 7
8 FM/AM	SHIFT + USB 8 — Shift + 8
8 TV	USB 8 — 8

Original	Replacement
9 FM/AM	SHIFT + BLUETOOTH 9 — Shift + 9
9 TV	BLUETOOTH 9 — 9
TV RETURN 10 — 10 FM/AM	SHIFT + PC FAV MARKER — Shift + Fav / Marker / PC
TV RETURN 10 — 10/Tv Return TV	SHIFT + HDMI - SAT 0 — Shift + 0
0 TV	HDMI - SAT 0 — 0
100+ +10 — +10/100+	SHIFT + -/-- GUIDE EPG — Shift + Guide / EPG / -/--
100+ +10 — +10 TV	PC FAV MARKER — Fav / Marker / PC

Original	Replacement

Original		Replacement	
	Power DVD		Power
	I<<	PRESET-	I<< / Preset-
	Play	SLOW	Play / Slow
	>>I	PRESET+	>>I / Preset+
	<<	TUNE-	<< / Tune-
	Stop	HOLD	Stop / Hold
	Pause	STEP - FREEZE	Pause / Step / Freeze
	Top Menu	TOP MENU D.MENU	D.Menu / Top
	>>	TUNE+	>> / Tune+
	Up		Up
	Menu	HOME MENU	Menu / Home
	Left	SHIFT +	Shift + Left
	Enter	OK	OK
	Right		Right
	Set Up	OPT-TOOLS SETUP	Setup / OPT /
	Down		Down
	On Screen	SHIFT + MEDIA DISPLAY	Shift + Display / Media

Original		Replacement	
	Audio	LANG I/II AUDIO	Audio / Lang I/II
	Subtitle	EQ SUBTITLE	Subtitle / EQ
	Title Group	SHIFT + TITLE SOUND	Shift + Sound / Title
	Return	RETURN BACK	Back / Return
	DVD Zoom	SIZE ZOOM	Zoom / Size
	1	TV 1	1
	2	DVD 2	2
	3	CD - STB 3	3
	VFP Progressive	LIST SMART	Smart / List
	4	VIDEO 4	4
	5	TAPE 5	5
	6	TUNER 6	6
	←		Left
	7	AUX - HDD 7	7
	8	USB 8	8
	9	BLUETOOTH 9	9
	Angle	ANGLE INFO	Info / Angle

Original		Replacement	
TV RETURN 10	10	GUIDE EPG	Guide / EPG / -/--
0	0	HDMI - SAT 0	0
100+ +10	+10	PC FAV MARKER	Fav / Marker / PC
DIMMER	Display/Dimmer	MEDIA DISPLAY	Display / Media
ANALOG/DIGITAL INPUT	Input Analog/Digital	RDS AV INPUT	AV / Input / RDS
CANCEL	Cancel	CLEAR EXIT CANCEL	Exit / Cancel / Clear
EFFECT	HDD Sound Effect	TITLE SOUND	Sound / Title
SURROUND	Surround	SURROUND	Eject / Surround

Original	Replacement

Original		Replacement	
	Power VCR	SHIFT + Power	Shift + Power
	Power STB	Power	Power
	VCR	SHIFT + GUIDE EPG	Shift + Guide / EPG / -/--
	Muting	DIMMER MUTE	Mute / Dimmer
	Channel+	CH PAGE +	CH+ / Page+
	Volume+	VOL +	Vol+
	Channel-	CH PAGE −	CH- / Page-
	Volume-	VOL −	Vol-
	Play VCR	SLOW ▶	Play / Slow
	<< VCR	TUNE- ◀◀	<< / Tune-
	Stop/Memory	HOLD ■	Stop / Hold
	Pause VCR	STEP-FREEZE ❚❚	Pause / Step / Freeze
	>> VCR	TUNE+ ▶▶	>> / Tune+
	1 VCR	SHIFT + TV 1	Shift + 1
	1 STB	TV 1	1
	2 VCR	SHIFT + DVD 2	Shift + 2
	2 STB	DVD 2	2

Original		Replacement	
	3 VCR	SHIFT + CD-STB 3	Shift + 3
	3 STB	CD-STB 3	3
	4 VCR	SHIFT + VIDEO 4	Shift + 4
	4 STB	VIDEO 4	4
	5 VCR	SHIFT + TAPE 5	Shift + 5
	5 STB	TAPE 5	5
	6 VCR	SHIFT + TUNER 6	Shift + 6
	6 STB	TUNER 6	6
	7 VCR	SHIFT + AUX-HDD 7	Shift + 7
	7 STB	AUX-HDD 7	7
	8 VCR	SHIFT + USB 8	Shift + 8
	8 STB	USB 8	8
	9 VCR	SHIFT + BLUETOOTH 9	Shift + 9
	9 STB	BLUETOOTH 9	9
	+10 TV	TV RETURN 10	Guide / EPG / -/--
	0 VCR	SHIFT + HDMI-SAT 0	Shift + 0
	0 STB	HDMI-SAT 0	0