Mandis shop

R- 40A01

Original		Replacement	
	Power		Power
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	Source/[≡]		AV / Input / RDS
	0		0
	Normal/OK/[≡i]		OK
	PR+		CH+ / Page+
	Up		Up
	Vol -		Vol -
	Left/[≡+]		Left

Original		Replacement	
	Menu		Menu / Home
	Right/[≡o]		Right
	Vol +		Vol +
	Down		Down
	PR-		CH- / Page-
	Sleep/[≡♦]		Sleep / Timer
	Mute		Mute / Dimmer
	Recall/[≡?]		Back / Return
	Red/Skip		Red / Netflix / Search
	Green/Movie		Green / APP / Repeat
	[≡x]		Exit / Cancel / Clear
	Yellow/Delete		Yellow / YouTube / Repeat
	Blue/Mode		Blue / Prime Video / Random
	[≡]		Text / Goto

https://aliexpress.com/item/1003279-replacement-remote-control-for-R-40A01/1000574830.html