Mandis shop

JVC RM-C3604

Original		Replacement	
Power	Power	Power	Power
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD - STB 3	3
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
7	7	AUX - HDD 7	7
8	8	USB 8	8
9	9	BLUETOOTH 9	9
Lang	Audio / Lang I/II	LANG I/II AUDIO	Audio / Lang I/II
0	0	HDMI - SAT 0	0
TXT	Text / Goto	GOTO TEXT	Text / Goto
V-	Vol-	VOL −	Vol-
V+	Vol+	+ VOL	Vol+
Mute	Mute / Dimmer	DIMMER MUTE	Mute / Dimmer
P+	CH+ / Page+	+ CH PAGE	CH+ / Page+

Original		Replacement	
P-	CH- / Page-	CH PAGE −	CH- / Page-
Source	AV / Input / RDS	RDS AV INPUT	AV / Input / RDS
Home	Menu / Home	HOME MENU	Menu / Home
[G]	Guide / EPG / -/--	-/-- GUIDE EPG	Guide / EPG / -/--
i	Info / Angle	ANGLE INFO	Info / Angle
Up	Up	Up	Up
Left	Left	Left	Left
OK	OK	OK	OK
Right	Right	Right	Right
Down	Down	Down	Down
Back	Back / Return	RETURN BACK	Back / Return
Exit	Exit / Cancel / Clear	CLEAR EXIT CANCEL	Exit / Cancel / Clear
Netflix	Shift + Red / Netflix /	SHIFT + NETFLIX SEARCH	Shift + Red / Netflix /
YouTube	Shift + Yellow / YouTube /	SHIFT + YouTube REPEAT A-B	Shift + Yellow / YouTube /
prime video	Shift + Blue / Prime	SHIFT + Prime Video RANDOM	Shift + Blue / Prime
Rakuten Tv	TV/Radio /	PROGRAM TV/ RADIO	TV/Radio /
twitch	Zoom / Size	SIZE ZOOM	Zoom / Size

Original		Replacement		Original		Replacement	
☆	☼1	OPT-TOOLS SETUP	Setup / OPT /				
	Red	NETFLIX SEARCH	Red / Netflix / Search				
	Green	APP REPEAT	Green / APP / Repeat				
	Yellow	YouTube REPEAT A-B	Yellow / YouTube / Repeat				
	Blue	Prime Video RANDOM	Blue / Prime Video / Random				
◀◀	<<	TUNE- ◀◀	<< / Tune-				
■	Stop	HOLD ■	Stop / Hold				
▶▶	>>	TUNE+ ▶▶	>> / Tune+				
●	Rec	REC MODE ●	Rec / Rec Mode				
▶	Play	SLOW ▶	Play / Slow				
❚❚	Pause	STEP-FREEZE ❚❚	Pause / Step / Freeze				