Original	Replacement	Original	Replacement
Power	Power	Music/Photo/Cam	3D
Mute	Mute	EPG	Guide
Tv/Radio	TV/R	Vol +	Vol +
FAV	Pre Ch	Vol -	Vol -
World/Internet	Smart	CH+	Ch +
1	1	CH-	Ch -
2	2	Exit	Exit
3	3	Info	Info
4	4	Back	Back
5	5	Menu	Menu
6	6	OK	Ok
7	7	Up	Up
8	8	Down	Down
9	9	Right	Right
0	0	Left	Left
LIB	List	Stop	Stop
P: P	AV	Play	Play

Original		Replacement		Original	Replacement
	Rec	REC MODE	Rec		
	Pause		Pause		
	>>		>>		
	<<		<<		
TEXT	Text	REPEAT TEXT	Text		
SUBT.	Subt.	AD SUBT	Subt		
AUDIO	Audio	SOUND DUAL	Dual		
OPT	OPT	SETTINGS OPT	Options		
	Red	A	Red		
	Green	B	Green		
	Yellow	C	Yellow		
	Blue	D	Blue		