Mandis shop

RC-601

Original		Replacement	
IN	IN		Up
IN	IN	CH PAGE +	CH+ / Page+
IN	IN		Right
IN	IN	VOL +	Vol+
OUT	OUT		Down
OUT	OUT	CH PAGE −	CH- / Page-
OUT	OUT		Left
OUT	OUT	VOL −	Vol-

Original	Replacement

https://alle-fernbedienungen.de/en/LAVA/1068113-27978-replacement-remote-control-for-LAVA-RC-601.html