Original		Replacement	
	Power		Power
OPEN/ CLOSE	Open/Close	ZOOM	Eject
1	1	1	1
2	2	2	2
3	3	3	3
4	4	4	4
5	5	5	5
6	6	6	6
7	7	7	7
8	8	8	8
9	9	9	9
0	0	0	0
CLEAR	Clear	CLEAR EXIT	Exit
REPEAT	Repeat	REPEAT TEXT	Text
	Play	PLAY MODE	Play
	Stop		Stop
	Pause		Pause

Original		Replacement	
	>>		>>
	<<		<<
	>>I		>>I
	I<<		I<<
DISC MENU	Disc Menu	E-MANUAL D.MENU	D. Menu
INFO/ MENU	Info/Menu	DISPLAY INFO	Info
BACK	Back	RETURN BACK	Back
HOME	Home	HOME SMART	Smart
TITLE/ POPUP	Title/Popup	SETTINGS OPT	Options
ENTER	Enter	OK	Ok
	Up		Up
	Down		Down
	Right		Right
	Left		Left
R	Red	A	Red
G	Green	B	Green
Y	Yellow	C	Yellow

Original		Replacement	
B	Blue	D	Blue
	Power Tv	SHIFT +	Shift + Power
INPUT	Input Tv	TIMER AV	AV
VOL−	Vol-	VOL −	Vol -
VOL+	Vol+	+ VOL	Vol +

Original	Replacement