Original	Replacement	Original	Replacement
Power	Power	Vol-	Vol -
Home	Smart	123/Input	AV
Back	Back	3D	3D
Micro	Dual	Mute/AD	Mute
Tv	TV/R	P+	Ch +
Mouse Down	>>	P-	Ch -
Mouse Up	<<		
Up	Up		
Down	Down		
Right	Right		
Left	Left		
OK	Ok		
Red	Red		
Green	Green		
Yellow	Yellow		
Blue	Blue		
Vol+	Vol +		

Original	Replacement
Power	Power
Wheel Down	SHIFT + ▼ Shift + Down
OK	OK Ok
Up	▲ Up
Down	▼ Down
Wheel Up	SHIFT + ▲ Shift + Up
Right	▶ Right
Left	◀ Left
Back	RETURN BACK Back
Home / Smart	HOME SMART Smart
3D	ECO 3D 3D
123 / Q.Menu	SHIFT + OK Shift + Ok
Vol +	+ VOL Vol +
Vol -	VOL − Vol -
Mute	MUTE Mute
P +	+ CH Ch +
P -	CH − Ch -

Original	Replacement
Ratio	PICTURE FORMAT Format
List	DISC NAV LIST List
Q.Menu	SHIFT + TOP MENU MENU Shift + Menu
Subtitle	AD SUBT Subt
Settings	SHIFT + SETTINGS OPT Shift + Options
AD / PIP	SOUND DUAL Dual
>>	>> >>
>>	>>I >>I
Play	PLAY MODE ▶ Play
<<	<< <<
<<	K<< I<<
Rec	REC MODE ● Rec
Pause	❚❚ Pause
Stop / Live TV	■ Stop
AV Mode	SHIFT + TIMER AV Shift + AV
Text	REPEAT TEXT Text
FAV	SHIFT + FAV PRE-CH Shift + Pre Ch

Original	Replacement
Exit	CLEAR EXIT — Exit
TV / PC	SHIFT + HOME SMART — Shift + Smart
Input	TIMER AV — AV
TV / Radio	SEARCH TV/R — TV/R
Blue	D — Blue
Yellow	C — Yellow
Green	B — Green
Red	A — Red
0	0 — 0
AD	SHIFT + AD SUBT — Shift + Subt
Search	SHIFT + SEARCH TV/R — Shift + TV/R
Live Menu	TOP MENU MENU — Menu
Recent	FAV PRE-CH — Pre Ch
Live Zoom	ZOOM ⏏ — Eject
App	SHIFT + APP MEDIA — Shift + Media
Guide	-/-- GUIDE — Guide
Info	DISPLAY INFO — Info

Original	Replacement
T.Opt	SETTINGS OPT — Options
Q.View	E-MANUAL D.MENU — D. Menu
Energy Saving	SHIFT + ECO 3D — Shift + 3D
9	9 — 9
8	8 — 8
7	7 — 7
6	6 — 6
5	5 — 5
4	4 — 4
3	3 — 3
2	2 — 2
1	1 — 1
My APPS	APP MEDIA — Media