Original		Replacement	
	Power		Power
	Open/Close		Eject
	Function		AV
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	0		0
	Clear		Exit
	Repeat↔		Text
	I<< Skip		I<<
	<<		<<

Original		Replacement	
	>>		>>
	Skip >>I		>>I
	Stop		Stop
	Play		Play
	Pause		Pause
	Vol +		Vol +
	Vol -		Vol -
	Mute		Mute
	Speaker Level		Options
	Sound Effect		Media
	Optical Tv Sound		TV/R
	Home		Smart
	Cinema Sound		Shift + Dual
	Info		Info
	Menu		Menu
	Up		Up
	Down		Down

Original		Replacement	
	Right		Right
	Left		Left
ENTER	Enter	OK	Ok
BACK	Back	RETURN BACK	Back
TITLE / POP UP	Title/Pop Up	DISC NAV LIST	List
DISC MENU	Disc Menu	E-MANUAL D.MENU	D. Menu
R	Red	A	Red
G	Green	B	Green
Y	Yellow	C	Yellow
B	Blue	D	Blue
SUBTITLE	Subtitle	AD SUBT	Subt
SLEEP	Sleep	PROG SLEEP	Sleep
AUDIO	Audio	SOUND DUAL	Dual
*	*	SHIFT + REPEAT TEXT	Shift + Text
	Power Tv	SHIFT +	Shift + Power
AV / INPUT	Av/Input Tv	SHIFT + SEARCH TV/R	Shift + TV/R
VOL+	Vol + Tv	SHIFT + + VOL	Shift + Vol +

Original		Replacement	
VOL−	Vol - Tv	SHIFT + VOL −	Shift + Vol -
PR/CH	Pr/Ch + Tv	+ CH	Ch +
PR/CH	Pr/Ch - Tv	CH −	Ch -