Original		Replacement	
POWER	Power		Power
MARKER	Marker	HOME SMART	Smart
OPEN/CLOSE	Open/Close	ZOOM	Eject
SEARCH	Search	SEARCH TV/R	TV/R
AUDIO	Audio	SOUND DUAL	Dual
SUBTITLE	Subtitle	AD SUBT	Subt
ANGLE	Angle	A	Red
RANDOM	Random	APP MEDIA	Media
PROGRAM	Program	PROG SLEEP	Sleep
CLEAR	Clear	CLEAR EXIT	Exit
1	1	1	1
2	2	2	2
3	3	3	3
4	4	4	4
5	5	5	5
6	6	6	6
7	7	7	7

Original		Replacement	
8	8	8	8
9	9	9	9
0	0	0	0
SKIP	I<<		I<<
PLAY	Play	PLAY MODE	Play
SKIP	>>I		>>I
ZOOM	Zoom	SHIFT + ZOOM	Shift + Eject
STOP	Stop		Stop
PAUSE/STEP	Pause/Step		Pause
DISPLAY	Display	DISPLAY INFO	Info
SLOW	<I Slow		<<
SLOW	Slow I>		>>
SELECT/ENTER	Select/Enter	OK	Ok
	Up		Up
	Down		Down
	Right		Right
	Left		Left

Original	Replacement	Original	Replacement
MENU	Menu	TOP MENU MENU	Menu
TITLE	Title	DISC NAV LIST	List
SETUP	Setup	SETTINGS OPT	Options
RETURN	Return	RETURN BACK	Back
REPEAT	Repeat	REPEAT TEXT	Text
A-B	A-B	PICTURE FORMAT	Format