Original		Replacement	
	Power		Power
ENERGY	Energy	SURROUND	Eject / Surround
AV MODE	AV. Mode	SIZE ZOOM	Zoom / Size
INPUT	Input	RDS AV INPUT	AV / Input / RDS
TV / RAD	TV/Radio	PROGRAM TV/RADIO	TV/Radio /
1	1	TV 1	1
2 abc	2	DVD 2	2
3 def	3	CD - STB 3	3
4 ghi	4	VIDEO 4	4
5 jkl	5	TAPE 5	5
6 mno	6	TUNER 6	6
7 pqrs	7	AUX - HDD 7	7
8 tuv	8	USB 8	8
9 wxyz	9	BLUETOOTH 9	9
LIST	List	LIST SMART	Smart / List
0	0	HDMI - SAT 0	0
Q.VIEW	Q.View	MEDIA DISPLAY	Display / Media

Original		Replacement	
+	Vol +	+ VOL	Vol +
MARK FAV	FAV/Mark	PC FAV MARKER	Fav / Marker / PC
P	CH+	+ CH PAGE	CH+ / Page+
–	Vol -	VOL –	Vol -
CHAR/NUM 3D	3D/Char/Num	TITLE SOUND	Sound / Title
P	CH-	CH PAGE –	CH- / Page-
DELETE MUTE	Mute/Delete	DIMMER MUTE	Mute / Dimmer
Premium	Premium	TIMER SLEEP	Sleep / Timer
Home	Home	HOME MENU	Menu / Home
3D OPTION Q.MENU	Q.Menu/3D	TOP MENU D.MENU	D.Menu / Top
	Up		Up
	Left		Left
OK	OK	OK	OK
	Right		Right
	Down		Down
BACK	Back	RETURN BACK	Back / Return
GUIDE	Guide	-/-- GUIDE EPG	Guide / EPG / -/--

Original		Replacement		Original	Replacement
EXIT	Exit	CLEAR EXIT CANCEL	Exit / Cancel / Clear		
	Red	NETFLIX SEARCH	Red / Netflix / Search		
	Green	APP REPEAT	Green / APP / Repeat		
	Yellow	YouTube REPEAT A-B	Yellow / YouTube / Repeat		
	Blue	Prime Video RANDOM	Blue / Prime Video / Random		
TEXT	Text	GOTO TEXT	Text / Goto		
T.OPT	T. OPT	OPT-TOOLS SETUP	Setup / OPT /		
SUBTITLE	Subtitle	EQ SUBTITLE	Subtitle / EQ		
	Stop	HOLD	Stop / Hold		
	Play	SLOW	Play / Slow		
	Pause	STEP-FREEZE	Pause / Step / Freeze		
	<<	TUNE-	<< / Tune-		
	>>	TUNE+	>> / Tune+		
REC	REC	REC MODE	Rec / Rec Mode		
INFO	Info	ANGLE INFO	Info / Angle		
AD	AD	LANG I/II AUDIO	Audio / Lang I/II		
RATIO	Ratio	FORMAT PICTURE	Picture / Format		