Mandis shop

LG 6710CMAQ05Q

Original		Replacement	
POWER	Power		Power
MUTE	Mute	DIMMER MUTE	Mute / Dimmer
PRESET/FOLDER	Preset/Folder Up	CH PAGE +	CH+ / Page+
VOLUME	Vol+	VOL +	Vol+
	Preset/Folder	CH PAGE –	CH- / Page-
FUNCTION	Function	HOME MENU	Menu / Home
	Vol-	VOL –	Vol-
SLEEP	Sleep	TIMER SLEEP	Sleep / Timer
▶/II	Play	SLOW ▶	Play / Slow
▶/II	Pause	STEP · FREEZE II	Pause / Step / Freeze
TUN.–	Tun-/I<<</<<	TUNE-	<< / Tune-
■	Stop	HOLD ■	Stop / Hold
TUN.+	>>/>>I/Tuner+	TUNE+	>> / Tune+
REPEAT	Repeat	APP REPEAT	Green / APP / Repeat
PROGRAM /MEMO	Program/Memo	PROGRAM TV/ RADIO	TV/Radio /
RDS	RDS	RDS AV INPUT	AV / Input / RDS
PTY	PTY	FORMAT PICTURE	Picture / Format

Original		Replacement	
PTY SEARCH	PTY Search	NETFLIX SEARCH	Red / Netflix / Search
EQ	EQ	EQ SUBTITLE	Subtitle / EQ
XDSS plus	XDSS Plus	LANG I/II AUDIO	Audio / Lang I/II
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD · STB 3	3
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
MP3 Info	MP3 Info	ANGLE INFO	Info / Angle
7	7	AUX · HDD 7	7
8	8	USB 8	8
9	9	BLUETOOTH 9	9
0	0	HDMI · SAT 0	0

https://alle-fernbedienungen.de/en/LG/1065558-86364-replacement-remote-control-for-LG-6710CMAQ05Q.html