Original		Replacement	
Power		Power	
TV		SHIFT + TV 1	Shift + 1
Caption		EQ SUBTITLE	Subtitle / EQ
AV Mode		SURROUND	Eject / Surround
RATIO	[ ]/Ratio	PROGRAM TV/RADIO	TV/Radio /
INPUT	Input	RDS AV INPUT	AV / Input / RDS
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD - STB 3	3
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
7	7	AUX - HDD 7	7
8	8	USB 8	8
9	9	BLUETOOTH 9	9
LIST	List	LIST SMART	Smart / List
0	0	HDMI - SAT 0	0

Original		Replacement	
FLASHBK	Flashbk	GOTO TEXT	Text / Goto
VOL	Vol+	+ VOL	Vol+
FAV	FAV	PC FAV MARKER	Fav / Marker / PC
CH PAGE	CH/Page-	CH PAGE −	CH- / Page-
CH PAGE	CH/Page+	+ CH PAGE	CH+ / Page+
VOL	Vol-	VOL −	Vol-
AUDIO	Audio	LANG I/II AUDIO	Audio / Lang I/II
MUTE	Mute	DIMMER MUTE	Mute / Dimmer
PICTURE	Picture	FORMAT PICTURE	Picture / Format
INFO	Info	ANGLE INFO	Info / Angle
SOUND	Sound	TITLE SOUND	Sound / Title
SETTINGS	Settings	OPT-TOOLS SETUP	Setup / OPT /
	Up		Up
Q.MENU	Q.Menu	TOP MENU D.MENU	D.Menu / Top
	Left		Left
OK	OK	OK	OK
	Right		Right

Original		Replacement	
BACK	Back	RETURN BACK	Back / Return
▼	Down	▼	Down
EXIT	Exit	CLEAR EXIT CANCEL	Exit / Cancel / Clear
SIMPLINK	Simplink	MEDIA DISPLAY	Display / Media
SLEEP	Sleep	TIMER SLEEP	Sleep / Timer
■	Stop	HOLD ■	Stop / Hold
◀◀	<<	TUNE- ◀◀	<< / Tune-
▶	Play	SLOW ▶	Play / Slow
II	Pause	STEP-FREEZE II	Pause / Step / Freeze
▶▶	>>	TUNE+ ▶▶	>> / Tune+
●	Red	NETFLIX SEARCH	Red / Netflix / Search
●●	Green	APP REPEAT	Green / APP / Repeat
●●●	Yellow	YouTube REPEAT A-B	Yellow / YouTube / Repeat
●●●●	Blue	Prime Video RANDOM	Blue / Prime Video / Random

Original	Replacement