Original		Replacement	
	Power		Power
	Energy Saving		Text / Goto
	AV Mode		Picture / Format
	Input		AV / Input / RDS
	Tv/Rad		TV/Radio /
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	List		Smart / List
	0		0
	Q.View		Setup / OPT / Tools

Original		Replacement	
	Vol +		Vol +
	FAV/Mark		Fav / Marker / PC
	CH+		CH+ / Page+
	Vol -		Vol -
	Ratio		Eject / Surround
	CH-		CH- / Page-
	Mute		Mute / Dimmer
	Guide		Guide / EPG / -/--
	Home		Menu / Home
	Q.Menu		D.Menu / Top
	Up		Up
	Left		Left
	Enter		OK
	Right		Right
	Down		Down
	Back		Back / Return
	Info		Info / Angle

Original		Replacement		Original		Replacement	
EXIT	Exit	CLEAR EXIT CANCEL	Exit / Cancel / Clear				
	Red	NETFLIX SEARCH	Red / Netflix / Search				
	Green	APP REPEAT	Green / APP / Repeat				
	Yellow	YouTube REPEAT A-B	Yellow / YouTube / Repeat				
	Blue	Prime Video RANDOM	Blue / Prime Video / Random				
	Stop	HOLD	Stop / Hold				
	Play	SLOW	Play / Slow				
FREEZE	Pause/Freeze	STEP-FREEZE	Pause / Step / Freeze				
	<<	TUNE-	<< / Tune-				
	>>	TUNE+	>> / Tune+				
FREEZE SIMPLINK	Simplink	MEDIA DISPLAY	Display / Media				
SUBTITLE	Subtitle	EQ SUBTITLE	Subtitle / EQ				