Original		Replacement	
	Power		Power
	[. . .]	AD SUBT	Subt
	Audio	SOUND DUAL	Dual
	Picture/[■]	PICTURE FORMAT	Format
	Recall/V≡	FAV PRE-CH	Pre Ch
	T-C/Guide	-/-- GUIDE	Guide
	OSD/Mute	MUTE	Mute
1	1	1	1
2	2	2	2
3	3	3	3
4	4	4	4
5	5	5	5
6	6	6	6
7	7	7	7
8	8	8	8
9	9	9	9
0	0	0	0

Original		Replacement	
T	T	REPEAT TEXT	Text
M	M	TOP MENU MENU	Menu
i	I>/i	DISPLAY INFO	Info
E	E	CLEAR EXIT	Exit
	Up		Up
	Down		Down
	Right		Right
	Left		Left
OK	OK	OK	Ok
	Red	A	Red
	Green	B	Green
	Yellow	C	Yellow
	Blue	D	Blue
	<<</I<		<<
	Stop		Stop
	Play	PLAY MODE	Play
T	Pause		Pause

Original	Replacement	Original	Replacement
>>/ >I	>>		

Original		Replacement	
	Power		Power
	[. . .]	AD SUBT	Subt
	Audio	SOUND DUAL	Dual
	Picture/[■]	PICTURE FORMAT	Format
	Recall/V≡	FAV PRE-CH	Pre Ch
	T-C/Guide	-/-- GUIDE	Guide
	OSD/Mute	MUTE	Mute
1	1	1	1
2	2	2	2
3	3	3	3
4	4	4	4
5	5	5	5
6	6	6	6
7	7	7	7
8	8	8	8
9	9	9	9
0	0	0	0

Original		Replacement	
T	T	REPEAT TEXT	Text
M	M	TOP MENU MENU	Menu
E	E	CLEAR EXIT	Exit
i	I>/i	DISPLAY INFO	Info
	Up		Up
	Down		Down
	Right		Right
	Left		Left
OK	OK	OK	Ok
	Red	A	Red
	Green	B	Green
	Yellow	C	Yellow
	Blue	D	Blue
	<<</I<		<<
	Stop		Stop
	Play	PLAY MODE	Play
T	Pause		Pause

Original		Replacement		Original		Replacement	
	>>I >I		>>				

Original		Replacement	
	Power		Power
	[. . .]	AD SUBT	Subt
	Audio	SOUND DUAL	Dual
	Picture/[■]	PICTURE FORMAT	Format
	Recall/V≡	FAV PRE-CH	Pre Ch
	T-C/Guide	GUIDE	Guide
	OSD/Mute	MUTE	Mute
1	1	1	1
2	2	2	2
3	3	3	3
4	4	4	4
5	5	5	5
6	6	6	6
7	7	7	7
8	8	8	8
9	9	9	9
0	0	0	0

Original		Replacement	
T	T	REPEAT TEXT	Text
M	M	TOP MENU MENU	Menu
E	E	CLEAR EXIT	Exit
	Up		Up
	Down		Down
	Right		Right
	Left		Left
OK	OK	OK	Ok
	Red	A	Red
	Green	B	Green
	Yellow	C	Yellow
	Blue	D	Blue
	<<|<		<<
	Stop		Stop
	Play	PLAY MODE	Play
T	Pause		Pause
	>>|>		>>