| Original | | Replacement | |
|---|---|---|---|
| POWER | Power | | Power |
| CH / PAGE | CH/Page+ | + CH | Ch + |
| | CH/Page- | CH − | Ch - |
| SLEEP | Sleep | PROG SLEEP | Sleep |
| MUTE | Mute | MUTE | Mute |
| VOLUME | Volume+ | + VOL | Vol + |
| | Volume- | VOL − | Vol - |
| INFO | Info | DISPLAY INFO | Info |
| OPTION | Option | SETTINGS OPT | Options |
| SETUP | Setup | TOP MENU MENU | Menu |
| BACK | Back | RETURN BACK | Back |
| | Up | | Up |
| ENTER | Enter | OK | Ok |
| | Down | | Down |
| | Right | | Right |
| | Left | | Left |
| | Play | PLAY MODE | Play |

| Original | | Replacement | |
|---|---|---|---|
| | Pause | | Pause |
| | Stop | | Stop |
| HOME | Home | HOME SMART | Smart |
| TUNE + | >>I/Tune+ | | >>I |
| − TUNE | I<<</Tune- | | I<< |
| | >> | | >> |
| | << | | << |
| MOVIE | Green/Movie | B | Green |
| MUSIC | Red/Music | A | Red |
| GAME | Blue/Game | D | Blue |
| PURE | Yellow/Pure | C | Yellow |
| 1 | 1 | 1 | 1 |
| 2 | 2 | 2 | 2 |
| 3 | 3 | 3 | 3 |
| 4 | 4 | 4 | 4 |
| 5 | 5 | 5 | 5 |
| 6 | 6 | 6 | 6 |

| Original | | Replacement | |
|---|---|---|---|
| 7 | 7 | 7 | 7 |
| 8 | 8 | 8 | 8 |
| 9 | 9 | 9 | 9 |
| 0 | 0 | 0 | 0 |
| 1 | Smart Select 1 | REPEAT TEXT | Text |
| 2 | Smart Select 2 | TIMER AV | AV |
| 3 | Smart Select 3 | PICTURE FORMAT | Format |
| 4 | Smart Select 4 | ECO 3D | 3D |
| TV AUDIO | TV Audio | SEARCH TV/R | TV/R |
| CBL/SAT | CBL/SAT | SHIFT + 1 | Shift + 1 |
| DVD | DVD | SHIFT + 2 | Shift + 2 |
| Blu-ray | Blu-ray | SHIFT + 3 | Shift + 3 |
| AUX1 | AUX1 | SHIFT + 4 | Shift + 4 |
| TUNER | Tuner | SHIFT + 5 | Shift + 5 |
| Bluetooth | Bluetooth | SHIFT + 6 | Shift + 6 |
| GAME | Game | SHIFT + 7 | Shift + 7 |
| PHONO | Phono | SHIFT + 9 | Shift + 9 |

| Original | | Replacement | |
|---|---|---|---|
| AUX2 | AUX2 | SHIFT + 8 | Shift + 8 |
| USB | USB | -/-- GUIDE | Guide |
| MEDIA PLAYER | Media Player | SHIFT + -/-- GUIDE | Shift + Guide |
| INTERNET RADIO | Internet Radio | FAV PRE-CH | Pre Ch |
| CD | CD | SHIFT + 0 | Shift + 0 |
| | Heos (Online | SHIFT + FAV PRE-CH | Shift + Pre Ch |

| Original | | Replacement | |
|---|---|---|---|
| POWER | Power | | Power |
| CH / PAGE | CH/Page+ | + CH | Ch + |
| | CH/Page- | CH − | Ch - |
| SLEEP | Sleep | PROG SLEEP | Sleep |
| MUTE | Mute | MUTE | Mute |
| VOLUME | Volume+ | + VOL | Vol + |
| | Volume- | VOL − | Vol - |
| BACK | Back | RETURN BACK | Back |
| | Up | | Up |
| | Down | | Down |
| | Right | | Right |
| | Left | | Left |
| ENTER | Enter | OK | Ok |
| HOME | Home | HOME SMART | Smart |
| | Stop | | Stop |
| | Pause | | Pause |
| | Play | PLAY MODE | Play |

| Original | | Replacement | |
|---|---|---|---|
| | >> | | >> |
| | << | | << |
| TUNE + | >>I/Tune+ | | >>I |
| − TUNE | I<<Tune- | | I<< |
| 1 | 1 | 1 | 1 |
| 2 | 2 | 2 | 2 |
| 3 | 3 | 3 | 3 |
| 4 | 4 | 4 | 4 |
| 5 | 5 | 5 | 5 |
| 6 | 6 | 6 | 6 |
| 7 | 7 | 7 | 7 |
| 8 | 8 | 8 | 8 |
| 9 | 9 | 9 | 9 |
| 0 | 0 | 0 | 0 |
| 1 | Smart Select 1 | REPEAT TEXT | Text |
| 2 | Smart Select 2 | TIMER AV | AV |
| 3 | Smart Select 3 | PICTURE FORMAT | Format |

| Original | Replacement | Original | Replacement |
|---|---|---|---|
| 4 Smart Select 4 | ECO 3D 3D | | |
| TV AUDIO TV Audio | SEARCH TV/R TV/R | | |
| MEDIA PLAYER Media Player | SHIFT + GUIDE Shift + Guide | | |
| INTERNET RADIO Internet Radio | FAV PRE-CH Pre Ch | | |
| CBL/SAT CBL/SAT | SHIFT + 1 Shift + 1 | | |
| DVD DVD | SHIFT + 2 Shift + 2 | | |
| Blu-ray Blu-ray | SHIFT + 3 Shift + 3 | | |
| AUX1 AUX1 | SHIFT + 4 Shift + 4 | | |
| TUNER Tuner | SHIFT + 5 Shift + 5 | | |
| Bluetooth Bluetooth | SHIFT + 6 Shift + 6 | | |
| GAME Game | SHIFT + 7 Shift + 7 | | |
| AUX2 AUX2 | SHIFT + 8 Shift + 8 | | |
| PHONO Phono | SHIFT + 9 Shift + 9 | | |
| USB USB | GUIDE Guide | | |
| CD CD | SHIFT + 0 Shift + 0 | | |
| Online Music | SHIFT + FAV PRE-CH Shift + Pre Ch | | |
| | | | |

| Original | | Replacement | |
|---|---|---|---|
| POWER | Power | | Power |
| CH / PAGE | CH/Page+ | + CH | Ch + |
| | CH/Page- | CH − | Ch - |
| SLEEP | Sleep | PROG SLEEP | Sleep |
| MUTE | Mute | MUTE | Mute |
| VOLUME | Volume+ | + VOL | Vol + |
| | Volume- | VOL − | Vol - |
| BACK | Back | RETURN BACK | Back |
| | Up | | Up |
| | Down | | Down |
| | Right | | Right |
| | Left | | Left |
| ENTER | Enter | OK | Ok |
| HOME | Home | HOME SMART | Smart |
| | Stop | | Stop |
| | Pause | | Pause |
| | Play | PLAY MODE | Play |

| Original | | Replacement | |
|---|---|---|---|
| TUNE + | >>I/Tune+ | | >>I |
| − TUNE | I<</Tune- | | I<< |
| | << | | << |
| | >> | | >> |
| 1 | 1 | 1 | 1 |
| 2 | 2 | 2 | 2 |
| 3 | 3 | 3 | 3 |
| 4 | 4 | 4 | 4 |
| 5 | 5 | 5 | 5 |
| 6 | 6 | 6 | 6 |
| 7 | 7 | 7 | 7 |
| 8 | 8 | 8 | 8 |
| 9 | 9 | 9 | 9 |
| 0 | 0 | 0 | 0 |
| 1 | Smart Select 1 | REPEAT TEXT | Text |
| 2 | Smart Select 2 | TIMER AV | AV |
| 3 | Smart Select 3 | PICTURE FORMAT | Format |

| Original | Replacement | Original | Replacement |
|---|---|---|---|
| 4 Smart Select 4 | ECO 3D: 3D | | |
| TV AUDIO TV Audio | SEARCH TV/R: TV/R | | |
| MEDIA PLAYER Media Player | SHIFT + GUIDE: Shift + Guide | | |
| INTERNET RADIO Internet Radio | FAV PRE-CH: Pre Ch | | |
| CBL/SAT CBL/SAT | SHIFT + 1: Shift + 1 | | |
| DVD DVD | SHIFT + 2: Shift + 2 | | |
| Blu-ray Blu-ray | SHIFT + 3: Shift + 3 | | |
| AUX1 AUX1 | SHIFT + 4: Shift + 4 | | |
| TUNER Tuner | SHIFT + 5: Shift + 5 | | |
| Bluetooth Bluetooth | SHIFT + 6: Shift + 6 | | |
| GAME Game | SHIFT + 7: Shift + 7 | | |
| AUX2 AUX2 | SHIFT + 8: Shift + 8 | | |
| PHONO Phono | SHIFT + 9: Shift + 9 | | |
| USB USB | GUIDE: Guide | | |
| CD CD | SHIFT + 0: Shift + 0 | | |
| Online Music | SHIFT + FAV PRE-CH: Shift + Pre Ch | | |
| | | | |