<table>
<tr><th>Original</th><th>Replacement</th><th>Original</th><th>Replacement</th></tr>
<tr><td>Power</td><td>Power</td><td>i / OSD</td><td>Display / Media</td></tr>
<tr><td>1</td><td>1</td><td>Z/Disc Menu</td><td>Menu / Home</td></tr>
<tr><td>2</td><td>2</td><td>Up</td><td>Up</td></tr>
<tr><td>3</td><td>3</td><td>P+</td><td>CH+ / Page+</td></tr>
<tr><td>PIP</td><td>Info / Angle</td><td>Left</td><td>Left</td></tr>
<tr><td>4</td><td>4</td><td>Vol -</td><td>Vol -</td></tr>
<tr><td>5</td><td>5</td><td>OK</td><td>OK</td></tr>
<tr><td>6</td><td>6</td><td>Right</td><td>Right</td></tr>
<tr><td>[<>]</td><td>Picture / Format</td><td>Vol +</td><td>Vol +</td></tr>
<tr><td>>|</td><td>>>| / Preset+</td><td>TXT</td><td>Text / Goto</td></tr>
<tr><td>7</td><td>7</td><td><<</td><td><< / Tune-</td></tr>
<tr><td>8</td><td>8</td><td>Down</td><td>Down</td></tr>
<tr><td>9</td><td>9</td><td>P-</td><td>CH- / Page-</td></tr>
<tr><td>?</td><td>Smart / List</td><td>TV-G</td><td>Guide / EPG / -/--</td></tr>
<tr><td>|<</td><td>|<< / Preset-</td><td>>></td><td>>> / Tune+</td></tr>
<tr><td>0</td><td>0</td><td>Red/Image/|></td><td>Red / Netflix / Search</td></tr>
<tr><td>Mute</td><td>Mute / Dimmer</td><td>Green/Timer</td><td>Green / APP / Repeat</td></tr>
</table>

Original	Replacement	Original	Replacement
Play	SLOW Play / Slow		
Yellow/Pause	REPEAT A-B Yellow / YouTube / Repeat		
Pause	STEP-FREEZE Pause / Step / Freeze		
Blue/Sound	RANDOM Blue / Prime Video / Random		
Stop	HOLD Stop / Hold		
Blue/Sound	TITLE Sound / Title		

Original		Replacement	
	Power		Power
	1		1
	2		2
	3		3
	Audio		Audio / Lang I/II
	4		4
	5		5
	6		6
	[<>]		Zoom / Size
	>I		>>I / Preset+
	7		7
	8		8
	9		9
	?		Smart / List
	I<		I<< / Preset-
	0		0
	i / OSD		Display / Media

Original		Replacement	
	Disc Menu		D.Menu / Top
	Disc Menu		Menu / Home
	Up		Up
	P+		CH+ / Page+
	Left		Left
	Vol -		Vol -
	OK		OK
	Right		Right
	Vol +		Vol +
	TXT		Text / Goto
	<<		<< / Tune-
	Down		Down
	P-		CH- / Page-
	TV-G		Guide / EPG / -/--
	>>		>> / Tune+
	Red/Picture		Picture / Format
	Red/Picture		Red / Netflix / Search

Original	Replacement	Original	Replacement
Green / Timer	Sleep / Timer		
Play	Play / Slow		
Green / Timer	Green / APP / Repeat		
Yellow/Pause	Yellow / YouTube / Repeat		
Pause	Pause / Step / Freeze		
Blue/Sound	Sound / Title		
Stop	Stop / Hold		
Blue/Sound	Blue / Prime Video / Random		

Original	Replacement	Original	Replacement
Power	Power	i / OSD	Display / Media
1	1	Z/ Disc Menu	Menu / Home
2	2	Up	Up
3	3	P+	CH+ / Page+
Audio	Audio / Lang I/II	Left	Left
4	4	Vol -	Vol -
5	5	OK	OK
6	6	Right	Right
[<>]	Zoom / Size	Vol +	Vol +
>I	>>I / Preset+	TXT	Text / Goto
7	7	<<	<< / Tune-
8	8	Down	Down
9	9	P-	CH- / Page-
?	Smart / List	TV-G	Guide / EPG / -/--
I<	I<< / Preset-	>>	>> / Tune+
0	0	Red/Image/I>	Red / Netflix / Search
Mute	Mute / Dimmer	Red/Image/I>	Shift + Play / Slow

Original	Replacement	Original	Replacement
Green/Timer	Green / APP / Repeat		
Play	Play / Slow		
Green/Timer	Sleep / Timer		
Pause	Pause / Step / Freeze		
Yellow/Pause	Yellow / YouTube / Repeat		
Blue/Sound	Blue / Prime Video / Random		
Stop	Stop / Hold		
Blue/Sound	Sound / Title		

Original	Replacement	Original	Replacement
Power	Power	Z/Disc Menu	Menu / Home
1	1	P+	CH+ / Page+
2	2	Up	Up
3	3	Left	Left
PIP/Audio	Audio / Lang I/II	Vol -	Vol -
4	4	OK	OK
5	5	Right	Right
6	6	Vol +	Vol +
[<>]	Zoom / Size	TXT	Text / Goto
7	7	<<	<< / Tune-
8	8	P-	CH- / Page-
9	9	Down	Down
?	Smart / List	TV-G	Guide / EPG / -/--
I<	I<< / Preset-	>>	>> / Tune+
>I	>>I / Preset+	Red/Image/I>	Picture / Format
0	0	Red/Image/I>	Red / Netflix / Search
i / OSD	Display / Media	Green/Timer	Green / APP / Repeat

Original		Replacement		Original	Replacement
	Play	SLOW	Play / Slow		
	Green/Timer	TIMER SLEEP	Sleep / Timer		
	Yellow/Pause	YouTube REPEAT A-B	Yellow / YouTube / Repeat		
	Pause	STEP-FREEZE	Pause / Step / Freeze		
	Blue/Sound	Prime Video RANDOM	Blue / Prime Video / Random		
	Stop	HOLD	Stop / Hold		
	Blue/Sound	TITLE SOUND	Sound / Title		