| Original | | Replacement | |
|---|---|---|---|
| DVD/TV | DVD/TV | PROGRAM TV/RADIO | TV/Radio / |
| Power | Power | Power | Power |
| i | i | ANGLE INFO | Info / Angle |
| AV | AV | RDS AV INPUT | AV / Input / RDS |
| Red | Red | NETFLIX SEARCH | Red / Netflix / Search |
| Green | Green | APP REPEAT | Green / APP / Repeat |
| Yellow | Yellow | YouTube REPEAT A-B | Yellow / YouTube / Repeat |
| Blue | Blue | Prime Video RANDOM | Blue / Prime Video / Random |
| P+ | P+ | CH PAGE + | CH+ / Page+ |
| P+ | Up | | |
| V- | Vol - | VOL − | |
| V- | Left | | |
| V+ | Vol + | + VOL | |
| V+ | Right | | |
| P- | CH- / Page- | CH PAGE − | |
| P- | Down | | |
| MUTE | Mute | DIMMER MUTE | Mute / Dimmer |

| Original | | Replacement | |
|---|---|---|---|
| TV | TV | SIZE ZOOM | Zoom / Size |
| 1 | 1 | TV 1 | 1 |
| 2 | 2 | DVD 2 | 2 |
| 3 | 3 | CD-STB 3 | 3 |
| Recall | Recall | RETURN BACK | Back / Return |
| 4 | 4 | VIDEO 4 | 4 |
| 5 | 5 | TAPE 5 | 5 |
| 6 | 6 | TUNER 6 | 6 |
| 16:9 | 16:9 | FORMAT PICTURE | Picture / Format |
| 7 | 7 | AUX-HDD 7 | 7 |
| 8 | 8 | USB 8 | 8 |
| 9 | 9 | BLUETOOTH 9 | 9 |
| PP | PP | PC FAV MARKER | Fav / Marker / PC |
| S/M/D | S/M/D | -/-- GUIDE EPG | Guide / EPG / -/-- |
| 0 | 0 | HDMI-SAT 0 | 0 |
| MENU | Menu | HOME MENU | Menu / Home |
| EXIT | Exit | CLEAR EXIT CANCEL | Exit / Cancel / Clear |

| Original | | Replacement | |
|---|---|---|---|
| TITLE | [ =] | GOTO TEXT | Text / Goto |
| CLEAR | `/ =] | SHIFT + GOTO TEXT | Shift + Text / |
| ANGLE | [ =o] | SLOW | Play / Slow |
| ZOOM | [ =i ] | STEP-FREEZE | Pause / Step / Freeze |
| DIGEST | [ =+] | HOLD | Stop / Hold |
| P.M | [ =♦] | REC MODE | Rec / Rec Mode |
| MARK | [ =x] | TUNE- | << / Tune- |
| A-B | [ =?] | TUNE+ | >> / Tune+ |

| Original | Replacement |
|---|---|
| | |

| Original | | Replacement | |
|---|---|---|---|
| | Power | | Power |
| | 1 | TV 1 | 1 |
| | 2 | DVD 2 | 2 |
| | 3 | CD-STB 3 | 3 |
| | 4 | VIDEO 4 | 4 |
| | 5 | TAPE 5 | 5 |
| | 6 | TUNER 6 | 6 |
| | 7 | AUX-HDD 7 | 7 |
| | 8 | USB 8 | 8 |
| | 9 | BLUETOOTH 9 | 9 |
| | 0 | HDMI-SAT 0 | 0 |
| AUDIO | Audio | LANG I/II AUDIO | Audio / Lang I/II |
| SUB | SUB | EQ SUBTITLE | Subtitle / EQ |
| < | < | SHIFT + | Shift + Left |
| > | > | SHIFT + | Shift + Right |
| | Pause | STEP-FREEZE | Pause / Step / Freeze |
| | Open/Close | SURROUND | Eject / Surround |

| Original | | Replacement | |
|---|---|---|---|
| | I << | PRESET- | I << / Preset- |
| | Play | SLOW | Play / Slow |
| | >>I | PRESET+ | >>I / Preset+ |
| | << | TUNE- | << / Tune- |
| | Stop | HOLD | Stop / Hold |
| | >> | TUNE+ | >> / Tune+ |
| DISPLAY | Display | MEDIA DISPLAY | Display / Media |
| MENU | Menu | HOME MENU | Menu / Home |
| | Up | | Up |
| SETUP | Setup | OPT-TOOLS SETUP | Setup / OPT / |
| 3D | 3D | SHIFT + CD-STB 3 | Shift + 3 |
| | Left | | Left |
| ENTER | Enter | OK | OK |
| | Right | | Right |
| SEARCH | Search | NETFLIX SEARCH | Red / Netflix / Search |
| RETURN | Return | RETURN BACK | Back / Return |
| | Down | | Down |

| Original | | Replacement | | Original | Replacement |
|---|---|---|---|---|---|
| EXIT | Exit | CLEAR EXIT CANCEL | Exit / Cancel / Clear | | |
| TITLE | Title | TITLE SOUND | Sound / Title | | |
| CLEAR | Clear | SHIFT + | CLEAR EXIT CANCEL Shift + Exit / Cancel / Clear | | |
| ANGLE | Angle | ANGLE INFO | Info / Angle | | |
| ZOOM | Zoom | SIZE ZOOM | Zoom / Size | | |
| DIGEST | Digest | Prime Video RANDOM | Blue / Prime Video / Random | | |
| P.M | P.M | GOTO TEXT | Text / Goto | | |
| MARK | Mark | PC FAV MARKER | Fav / Marker / PC | | |
| A-B | A-B | YouTube REPEAT A-B | Yellow / YouTube / Repeat | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |