Original		Replacement	
ON/STANDBY	On / Standby	Power	
1 V1	Input Selector V1	TV 1	1
2 V2	Input Selector V2	VIDEO 4	4
3 V3	Input Selector V3	AUX - HDD 7	7
0 DIMMER	Dimmer	SHIFT + DIMMER MUTE	Shift + Mute / Dimmer
5 MULTI CH	Input Selector Multi CH	USB 8	8
RETURN	Return	RETURN BACK	Back / Return
SETUP	Setup	OPT-TOOLS SETUP	Setup / OPT /
ENTER	Enter	OK	OK
6 DVD	Input Selector	DVD 2	2
7 TAPE	Input Selector	TAPE 5	5
CLR SLEEP	Sleep	TIMER SLEEP	Sleep / Timer
8 TUNER	Input Selector Tuner	TUNER 6	6
GUIDE TOP MENU SP A/B	SP A/B	LANG I/II AUDIO	Audio / Lang I/II
PREVIOUS MENU MUTING	Muting	DIMMER MUTE	Mute / Dimmer
	Up		Up
	Down		Down

Original		Replacement	
PLAYLIST/CAT+	Right		Right
9 CD	Input Selector CD	CD - STB 3	3
-PLAYLIST/CAT	Left		Left
	Play	SLOW	Play / Slow
	Stop	HOLD	Stop / Hold
	<<	TUNE-	<< / Tune-
	Play Rev.	STEP - FREEZE	Pause / Step / Freeze
	>>	TUNE+	>> / Tune+
	I<<	PRESET-	I<< / Preset-
	>>I	PRESET+	>>I / Preset+
DISPLAY	Display	MEDIA DISPLAY	Display / Media
STEREO	Listening Mode Stereo	TITLE SOUND	Sound / Title
SURROUND	Listening Mode Surround	SURROUND	Eject / Surround
NG MODE	Listening Mode <	SHIFT + PRESET-	Shift + I<< / Preset-
	Listening Mode >	SHIFT + PRESET+	Shift + >>I / Preset+
AUDIO TEST TONE	Test Tone	GOTO TEXT	Text / Goto
RANDOM LEVEL-	Level-	CH PAGE	CH- / Page-

Original		Replacement	
VOL	Vol+	+ VOL	Vol+
SUBTITLE CH SEL	CH Sel	LIST SMART	Smart / List
REPEAT LEVEL+	Level+	+ CH PAGE	CH+ / Page+
L NIGHT DVD	L.Night	PROGRAM TV/RADIO	TV/Radio /
CINE FLTR HDD	Cine FLTR	TOP MENU D.MENU	D.Menu / Top
VOL	Vol-	VOL −	Vol-
TV INPUT	Input Tv	SHIFT + RDS AV INPUT	Shift + AV / Input / RDS
VOL	Vol+ Tv	SHIFT + + VOL	Shift + Vol+
VOL	Vol- Tv	SHIFT + VOL −	Shift + Vol-
CH DISC ALBUM −	CH/Disc/Album	SHIFT + + CH PAGE	Shift + CH+ /
+ CH DISC ALBUM	CH/Disc/Album-	SHIFT + CH PAGE −	Shift + CH- /
1 V1	1 Tv	SHIFT + TV 1	Shift + 1
2 V2	2 Tv	SHIFT + DVD 2	Shift + 2
TV	Power Tv/Standby	SHIFT +	Shift + Power
3 V3	3 Tv	SHIFT + CD - STB 3	Shift + 3
4	4 Tv	SHIFT + VIDEO 4	Shift + 4
6 DVD	6 Tv	SHIFT + TUNER 6	Shift + 6

Original		Replacement	
5 MULTI CH	5 Tv	SHIFT + TAPE 5	Shift + 5
7 TAPE	7 Tv	SHIFT + AUX - HDD 7	Shift + 7
8 TUNER	8 Tv	SHIFT + USB 8	Shift + 8
9 CD	9 Tv	SHIFT + BLUETOOTH 9	Shift + 9
0 11 DIMMER	0 Tv	SHIFT + HDMI - SAT 0	Shift + 0
+10 10 D TUN	+10 Tv	SHIFT + -/-- GUIDE EPG	Shift + Guide / EPG / -/--
ENTER	Enter Tv	SHIFT + OK	Shift + OK
PLAYLIST/CAT	Right Tv	SHIFT + ▶	Shift + Right
PREVIOUS MENU MUTING	Previous Menu Tv	SHIFT + PC FAV MARKER	Shift + Fav / Marker / PC
PLAYLIST/CAT	Left Tv	SHIFT + ◀	Shift + Left
SETUP	Setup Tv	SHIFT + OPT-TOOLS SETUP	Shift + Setup / OPT / Tools
	Up Tv	SHIFT + ▲	Shift + Up
	Down Tv	SHIFT + ▼	Shift + Down

Original		Replacement	
ON/STANDBY	Power		Power
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD-STB 3	3
4	4	VIDEO 4	4
5 MULTI CH	5	TAPE 5	5
6 DVD	6	TUNER 6	6
7 TAPE	7	AUX-HDD 7	7
8 TUNER	8	USB 8	8
9 CD	9	BLUETOOTH 9	9
VCR	VCR	SHIFT + VIDEO 4	Shift + 4
+10	+10/10/-/--	-/-- GUIDE EPG	Guide / EPG / -/--
0 DIMMER	0/11	HDMI-SAT 0	0
CLR	CLR	CLEAR EXIT CANCEL	Exit / Cancel / Clear
GUIDE TOP MENU SP A/B	Top Menu	TOP MENU D.MENU	D.Menu / Top
	Up		Up
PREVIOUS MENU MUTING	Previous Menu/Muting	HOME MENU	Menu / Home

Original		Replacement	
PREVIOUS MENU MUTING	Previous Menu/Muting	DIMMER MUTE	Mute / Dimmer
PLAYLIST/CAT-	Left/Playlist/Cat-		Left
ENTER	Enter	OK	OK
PLAYLIST/CAT+	Right/Playlist/Cat		Right
RETURN	Return	RETURN BACK	Back / Return
	Down		Down
SETUP	Setup	OPT-TOOLS SETUP	Setup / OPT /
	Pause	STEP-FREEZE	Pause / Step / Freeze
	Play	SLOW	Play / Slow
	Stop	HOLD	Stop / Hold
	<<	TUNE-	<< / Tune-
	>>	TUNE+	>> / Tune+
	I<<	PRESET-	I<< / Preset-
	>>I	PRESET+	>>I / Preset+
STEREO	Stereo	TITLE SOUND	Sound / Title
SURROUND	Surround	SURROUND	Eject / Surround
LISTENING MODE	< Listening Mode	SHIFT + PRESET-	Shift + I<< / Preset-

Original	Replacement
Listening Mode >	SHIFT + PRESET+ (Shift + >>I / Preset+)
AUDIO / TEST TONE	LANG I/II / AUDIO — Audio / Lang I/II
SUBTITLE / CH SEL	EQ / SUBTITLE — Subtitle / EQ
RANDOM / LEVEL-	Prime Video / RANDOM — Blue / Prime Video / Random
REPEAT / LEVEL+	APP / REPEAT — Green / APP / Repeat
DISPLAY	MEDIA / DISPLAY — Display / Media
PLAY MODE / VCR	FORMAT / PICTURE — Picture / Format
L NIGHT / DVD	SHIFT + DVD 2 — Shift + 2
CINE FLTR / HDD	SHIFT + AUX - HDD 7 — Shift + 7

Original	Replacement

Original		Replacement	
ON/STANDBY	On / Standby		Power
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD-STB 3	3
4	4	VIDEO 4	4
5 MULTI CH	5	TAPE 5	5
6 DVD	6	TUNER 6	6
7 TAPE	7	AUX-HDD 7	7
8 TUNER	8	USB 8	8
9 CD	9	BLUETOOTH 9	9
+10	+10/10/-/--	GUIDE EPG	Guide / EPG / -/--
0 DIMMER	0/11	HDMI-SAT 0	0
CLR	12	PC FAV MARKER	Fav / Marker / PC
CH DISC ALBUM +	Disc+	CH + PAGE	CH+ / Page+
VOL	Vol+	VOL +	Vol+
CH DISC ALBUM −	Disc-	CH PAGE −	CH- / Page-
VOL	Vol-	VOL −	Vol-

Original		Replacement	
	Pause	STEP-FREEZE	Pause / Step / Freeze
	Play	SLOW	Play / Slow
	Stop	HOLD	Stop / Hold
	<<	TUNE-	<< / Tune-
	>>	TUNE+	>> / Tune+
	I<<	PRESET-	I<< / Preset-
	>>I	PRESET+	>>I / Preset+
STEREO	Stereo	LANG I/II AUDIO	Audio / Lang I/II
SURROUND	Surround	SURROUND	Eject / Surround
NG MODE	< Listening Mode	SHIFT + PRESET-	Shift + I<< / Preset-
	Listening Mode >	SHIFT + PRESET+	Shift + >>I / Preset+
RANDOM LEVEL-	Random	Prime Video RANDOM	Blue / Prime Video / Random
REPEAT LEVEL+	Repeat	APP REPEAT	Green / APP / Repeat
DISPLAY	Display	MEDIA DISPLAY	Display / Media

Original		Replacement	
ON/STANDBY	Power		Power
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD-STB 3	3
4	4	VIDEO 4	4
5 MULTI CH	5	TAPE 5	5
6 DVD	6	TUNER 6	6
7 TAPE	7	AUX-HDD 7	7
8 TUNER	8	USB 8	8
9 CD	9	BLUETOOTH 9	9
+10	+10/10/-/--	-/-- GUIDE EPG	Guide / EPG / -/--
0 DIMMER	0/11	HDMI-SAT 0	0
CH DISC ALBUM +	CH+	CH PAGE +	CH+ / Page+
CH DISC ALBUM −	CH-	CH PAGE −	CH- / Page-
	Pause	STEP-FREEZE	Pause / Step / Freeze
	Play	SLOW	Play / Slow
	Stop	HOLD	Stop / Hold

Original		Replacement	
	<<	TUNE-	<< / Tune-
STEREO	Stereo	LANG I/II AUDIO	Audio / Lang I/II
SURROUND	Surround	SURROUND	Eject / Surround
NG MODE	< Listening Mode	SHIFT + PRESET-	Shift + I<< / Preset-
	Listening Mode >	SHIFT + PRESET+	Shift + >>I / Preset+
PLAY MODE VCR	Play Mode	TOP MENU D.MENU	D.Menu / Top
L NIGHT DVD	L.Night	TIMER SLEEP	Sleep / Timer