Original		Replacement	
	RCVR Sleep		Sleep / Timer
	RCVR On		Power
	RCVR Standby		Shift + Power
	RCVR Return		Back / Return
	RCVR Setup		Setup / OPT /
	RCVR Disc+		CH+ / Page+
	RCVR Up		Up
	RCVR Vol +		Vol +
	RCVR Disc-		CH- / Page-
	RCVR Left		Left
	RCVR Enter		OK
	RCVR Right		Right
	RCVR Vol -		Vol -
	RCVR Down		Down
	RCVR Audio		Audio / Lang I/II
	RCVR CH Sel / Top Menu		D.Menu / Top
	RCVR Test / Menu		Menu / Home

Original		Replacement	
	RCVR Muting		Mute / Dimmer
	RCVR Level		Shift + Down
	RCVR Level Up		Shift + Up
	RCVR I<<		I<< / Preset-
	RCVR Play		Play / Slow
	RCVR >>I		>>I / Preset+
	RCVR <<		<< / Tune-
	RCVR Stop		Stop / Hold
	RCVR >>		>> / Tune+
	RCVR Rec /		Blue / Prime Video / Random
	RCVR Pause / Play / Rev.		Pause / Step / Freeze
	RCVR Open / Close		Eject / Surround
	RCVR Input Sel.		2
	RCVR Input Sel.		3
	RCVR Input Sel.		4
	RCVR Input Sel.		1
	RCVR Input Sel.		5

TAP

Original		Replacement	
TUN	RCVR Input Sel.	TUNER 6	6
V3	RCVR Input Sel.	AUX - HDD 7	7
V4	RCVR Input Sel.	USB 8	8
V5	RCVR Input Sel.	BLUETOOTH 9	9
PH	RCVR Input Sel.	HDMI - SAT 0	0
1 STEREO	RCVR Stereo	SHIFT + TV 1	Shift + 1
2 DIRECT	RCVR Direct	SHIFT + DVD 2	Shift + 2
3 DSP ►	RCVR DSP ►	SHIFT + CD - STB 3	Shift + 3
4 SURR	RCVR SURR	SHIFT + VIDEO 4	Shift + 4
4 SURR	RCVR SURR	SHIFT + SURROUND ⏏	Shift + Eject / Surround
5 THX	RCVR THX	SHIFT + TAPE 5	Shift + 5
6 DSP ◄	RCVR ◄ DSP	SHIFT + TUNER 6	Shift + 6
7 SP A	RCVR SP A	SHIFT + AUX - HDD 7	Shift + 7
8 SP B	RCVR SP B	SHIFT + USB 8	Shift + 8
9 Re-EQ	RCVR Re-EQ	EQ SUBTITLE	Subtitle / EQ
9 Re-EQ	RCVR Re-EQ	SHIFT + BLUETOOTH 9	Shift + 9
+10 DISPLAY	RCVR Display	MEDIA DISPLAY	Display / Media

Original		Replacement	
0 DIMMER	RCVR Dimmer	SHIFT + HDMI - SAT 0	Shift + 0
0 DIMMER	RCVR Dimmer	SHIFT + DIMMER MUTE	Shift + Mute / Dimmer
SEARCH ZONE 2 ENTER	RCVR Zone 2	LIST SMART	Smart / List

Original		Replacement	
ON	ON	Power	Power
STDBY	STDBY	SHIFT + Power	Shift + Power
Return	RETURN	BACK	Back / Return
Setup	SETUP	OPT-TOOLS SETUP	Setup / OPT /
Disc+	CH DISC	CH PAGE +	CH+ / Page+
Up		Up	Up
Vol +	VOL	VOL +	Vol +
Disc-	CH DISC	CH PAGE −	CH- / Page-
Left		Left	Left
Enter	ENTER	OK	OK
Right		Right	Right
Vol -	VOL	VOL −	Vol -
Down		Down	Down
Top Menu	CH SEL TOP MENU	TOP MENU D.MENU	D.Menu / Top
Menu	TEST MENU	HOME MENU	Menu / Home
Muting	MUTING M	DIMMER MUTE	Mute / Dimmer
Angle	ANGLE LEVEL	ANGLE INFO	Info / Angle

Original		Replacement	
Subtitle	SUBTITLE LEVEL	EQ SUBTITLE	Subtitle / EQ
I<<		PRESET-	I<< / Preset-
Play		SLOW	Play / Slow
>>I		PRESET+	>>I / Preset+
<<		TUNE-	<< / Tune-
Stop		HOLD	Stop / Hold
>>		TUNE+	>> / Tune+
Random	RANDOM R	Prime Video RANDOM	Blue / Prime Video / Random
Pause		STEP-FREEZE	Pause / Step / Freeze
Open / Close	OPEN/CLOSE	SURROUND	Eject / Surround
1	1 STEREO	TV 1	1
2	2 DIRECT	DVD 2	2
3	3 DSP	CD-STB 3	3
4	4 SURR	VIDEO 4	4
5	5 THX	TAPE 5	5
6	6 DSP	TUNER 6	6
7	7 SP A	AUX-HDD 7	7

Original		Replacement		Original		Replacement	
8 SP B	8	USB 8	8				
9 Re-EQ	9	BLUETOOTH 9	9				
+10 DISPLAY	+10	-/-- GUIDE EPG	Guide / EPG / -/--				
0 DIMMER	0	HDMI - SAT 0	0				
SEARCH ZONE 2 ENTER	Search	NETFLIX SEARCH	Red / Netflix / Search				

Original		Replacement		Original		Replacement	
ON	ON	Power	Power	3	3	3	3
STDBY	STDBY	Shift + Power	SHIFT + Power	4	4	4	4
Disc+	CH DISC	CH+ / Page+	CH PAGE	5	5	5	5
Vol +	VOL	Vol +	VOL	6	6	6	6
Vol -	VOL	Vol -	VOL	7	7	7	7
Muting	MUTING	Mute / Dimmer	DIMMER MUTE	8	8	8	8
I<<		I<< / Preset-	PRESET-	9	9	9	9
Play		Play / Slow	SLOW	+10	+10	Guide / EPG / -/--	GUIDE EPG
>>I		>>I / Preset+	PRESET+	0	0	0	0
<<		<< / Tune-	TUNE-				
Stop		Stop / Hold	HOLD				
>>		>> / Tune+	TUNE+				
Random	RANDOM	Blue / Prime Video / Random	Prime Video RANDOM				
Pause		Pause / Step / Freeze	STEP-FREEZE				
	OPEN/CLOSE	Eject / Surround	SURROUND				
1	1 STEREO	1	TV 1				
2	2 DIRECT	2	DVD 2				

Original		Replacement	
ON	ON	Power	Power
STDBY	STDBY	SHIFT + Power	Shift + Power
Vol +	VOL +	Vol +	Vol +
Enter	ENTER	OK	OK
Enter	ENTER	FAV MARKER	Fav / Marker / PC
Vol -	VOL -	VOL -	Vol -
Muting	MUTING	DIMMER MUTE	Mute / Dimmer
I<<	I<<	PRESET-	I<< / Preset-
Play	Play	SLOW	Play / Slow
>>I	>>I	PRESET+	>>I / Preset+
<<	<<	TUNE-	<< / Tune-
Stop	Stop	HOLD	Stop / Hold
>>	>>	TUNE+	>> / Tune+
Rec / Random	RANDOM	Prime Video / RANDOM	Blue / Prime Video / Random
Rec / Random	RANDOM	REC MODE	Rec / Rec Mode
Pause	Pause	STEP-FREEZE	Pause / Step / Freeze
Open / Close	OPEN/CLOSE	SURROUND	Eject / Surround

Original		Replacement	
1 STEREO	1	TV 1	1
2 DIRECT	2	DVD 2	2
3 DSP	3	CD-STB 3	3
4 SURR	4	VIDEO 4	4
5 THX	5	TAPE 5	5
6 DSP	6	TUNER 6	6
7 SPA	7	AUX-HDD 7	7
8 SPB	8	USB 8	8
9 Re-EQ	9	BLUETOOTH 9	9
+10 DISPLAY	+10	-/-- GUIDE EPG	Guide / EPG / -/--
0 DIMMER	0	HDMI-SAT 0	0