Mandis shop

Panasonic N2QAEC000023

Original	Replacement
Start/Stop	Power
Photo Shot	Source
Ext/Display	9 / Disp
Date/Time	Eject / GOTO
Zoom T/Vol+	V+
Zoom W/Vol-	V-
<< Search	<<
Play	Play / Band
Search >>	>>
<I Still ADV	-
Pause	IIAng
Still ADV I>	+
I<< Skip	I<
Stop	Stop / Random
Skip >>I	>I
Delete/Spam	3 / Exit
Menu	2 / Menu

Original	Replacement
Up	Up
Down	Down
Right	Right
Left	Left
Enter	OK

https://alle-fernbedienungen.de/en/Panasonic/1056912-9523-replacement-remote-control-for-Panasonic-N2QAEC000023.html