Mandis shop

Panasonic N2QAYB000396

Original		Replacement	
	Power		Power
PLAY	Timer/Play	ANGLE INFO	Info / Angle
CLOCK/TIMER	Clock/Timer	SHIFT + TIMER SLEEP	Shift + Sleep / Timer
DIMMER	Dimmer	SHIFT + DIMMER MUTE	Shift + Mute / Dimmer
SLEEP	Sleep	TIMER SLEEP	Sleep / Timer
AUTO OFF	Auto Off	SHIFT +	Shift + Power
+ VOL	Vol+	+ VOL	Vol+
–	Vol-	VOL –	Vol-
MUTE	Mute	DIMMER MUTE	Mute / Dimmer
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD - STB 3	3
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
7	7	AUX - HDD 7	7
8	8	USB 8	8

Original		Replacement	
9	9	BLUETOOTH 9	9
0	0	HDMI - SAT 0	0
PROGRAM	Program	PROGRAM TV/ RADIO	TV/Radio /
≧10	+10	-/-- GUIDE EPG	Guide / EPG / -/--
DEL	Del	CLEAR EXIT CANCEL	Exit / Cancel / Clear
REPEAT	Repeat	APP REPEAT	Green / APP / Repeat
AUX	AUX	SHIFT + AUX - HDD 7	Shift + 7
PLAY MODE	Play Mode	SHIFT + SLOW ►	Shift + Play /
DAB/FM	DAB/FM	NETFLIX SEARCH	Red / Netflix / Search
⏮/◄◄	<<|<<	TUNE- ◄◄	<< / Tune-
►►/⏭	>>/>>|	TUNE+ ►►	>> / Tune+
■	Stop	HOLD ■	Stop / Hold
CD►/II	Play/Pause CD	SLOW ►	Play / Slow
DISPLAY	Display	MEDIA DISPLAY	Display / Media
iPod►/II	Play/Pause iPod	STEP - FREEZE II	Pause / Step / Freeze
RE-MASTER	Re-Master	FORMAT PICTURE	Picture / Format
SURROUND	Surround	SURROUND ⏏	Eject / Surround

Original	Replacement	Original	Replacement
D.BASS	Audio / Lang I/II		
Up	Up		
Down	Down		
iPod Menu	Menu / Home		
Right	Right		
Preset EQ	Subtitle / EQ		
Bass/Treble	Sound / Title		
Left	Left		
OK	OK		
DAB Menu	D.Menu / Top		
Auto Preset	Smart / List		
Tune Mode	Blue / Prime Video / Random		
DAB Secondary	Yellow / YouTube / Repeat		