| Original | | Replacement | |
|---|---|---|---|
| | Power | | Power |
| | Power Tv | SHIFT + | Shift + Power |
| | Vol + Tv | SHIFT + | Shift + Vol + |
| | Play Mode | GOTO TEXT | Text / Goto |
| | AV Tv | RDS AV INPUT | AV / Input / RDS |
| | Vol - Tv | SHIFT + | Shift + Vol - |
| | 1 | TV 1 | 1 |
| | 2 | DVD 2 | 2 |
| | 3 | CD-STB 3 | 3 |
| | Vol + | VOL | Vol + |
| | 4 | VIDEO 4 | 4 |
| | 5 | TAPE 5 | 5 |
| | 6 | TUNER 6 | 6 |
| | Vol - | VOL | Vol - |
| | 7 | AUX-HDD 7 | 7 |
| | 8 | USB 8 | 8 |
| | 9 | BLUETOOTH 9 | 9 |

| Original | | Replacement | |
|---|---|---|---|
| | Repeat | APP REPEAT | Green / APP / Repeat |
| | 0 | HDMI-SAT 0 | 0 |
| | +10 | -/-- GUIDE EPG | Guide / EPG / -/-- |
| | Mute | DIMMER MUTE | Mute / Dimmer |
| | DVD | SHIFT + DVD 2 | Shift + 2 |
| | iPod/USB | YouTube REPEAT A-B | Yellow / YouTube / Repeat |
| | Ext-In/Radio | PROGRAM TV/RADIO | TV/Radio / |
| | << | TUNE- | << / Tune- |
| | Play | SLOW | Play / Slow |
| | >> | TUNE+ | >> / Tune+ |
| | I << | PRESET- | I << / Preset- |
| | Pause | STEP-FREEZE | Pause / Step / Freeze |
| | >>I | PRESET+ | >>I / Preset+ |
| | Surround | LANG I/II AUDIO | Audio / Lang I/II |
| | Stop | HOLD | Stop / Hold |
| | Sound | TITLE SOUND | Sound / Title |
| | Start | LIST SMART | Smart / List |

| Original | | Replacement | | Original | Replacement |
|---|---|---|---|---|---|
| | Top Menu/Direct Navigator | | D. Menu / Top | | |
| | Up | | Up | | |
| | Functions | | Display / Media | | |
| | Left | | Left | | |
| | OK | | OK | | |
| | Right | | Right | | |
| | Menu/Play List | | Menu / Home | | |
| | Down | | Down | | |
| | Return | | Back / Return | | |
| | Setup/-CH Select | | Setup / OPT / | | |
| | W.SRD | | Zoom / Size | | |
| | FL Display/-Slee | | Info / Angle | | |
| | Cancel | | Exit / Cancel / Clear | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |