Mandis shop

# Panasonic N2QAYC000081

| Original | | Replacement | |
|---|---|---|---|
| POWER | Power | POWER | Power |
| iPod | Eject iPod | SHIFT + SURROUND | Shift + Eject / Surround |
| CD | Eject CD | SURROUND | Eject / Surround |
| iPod/ USB | iPod USB | LIST SMART | Smart / List |
| CD/ RADIO | CD/Radio | PROGRAM TV/ RADIO | TV/Radio / |
| BLUETOOTH | Bluetooth | BLUETOOTH 9 | 9 |
| ⏮/◀◀ | I<</<< | TUNE- ◀◀ | << / Tune- |
| ▶/II | Play | SLOW ▶ | Play / Slow |
| ▶/II | Pause | STEP-FREEZE II | Pause / Step / Freeze |
| ▶▶/⏭ | >>/>>I | TUNE+ ▶▶ | >> / Tune+ |
| ■ | Stop | HOLD ■ | Stop / Hold |
| VOL– | Vol - | VOL – | Vol - |
| VOL+ | Vol + | + VOL | Vol + |
| SETUP | Setup | OPT-TOOLS SETUP | Setup / OPT / |
| MUTE | Mute | DIMMER MUTE | Mute / Dimmer |
| iPod MENU DISPLAY | Display/iPod | MEDIA DISPLAY | Display / Media |
| SOUND | Sound | TITLE SOUND | Sound / Title |

| Original | | Replacement | |
|---|---|---|---|
| PLAY MENU | Play Menu | APP REPEAT | Green / APP / Repeat |
| ▼ | Album Up | ▲ | Up |
| OK | OK | OK | OK |
| ▲ | Album Down | ▼ | Down |

https://alle-fernbedienungen.de/Panasonic/1665-638-replacement-remote-control-for-Panasonic-N2QAYC000081.htm