Original	Replacement	Original	Replacement
Power	Power	Stop	Stop
Open/Close	Eject	Menu	Menu
CD/FM	Yellow	RDS/Display	Info
Dock	Blue	Repeat/Shuffle	Text
Audio In/USB	Red	Prog	Shift + Sleep
Preset/Album	Up	Sound	Dual
Preset/Album	Down	Clock	AV
>>I	>>I	Sleep/Timer	Sleep
>>I	Right		
I<<	I<<		
I<<	Left		
OK	Ok		
Vol +	Vol +		
Vol -	Vol -		
Mute	Mute		
Play	Play		
Pause	Pause		

Original	Replacement
Power	Power
Open/Close	Eject
CD/FM	Yellow
Dock	Blue
Audio In/USB	Red
Preset/Album	Up
Preset/Album	Down
>>I	>>I
>>I	Right
I<<	I<<
I<<	Left
OK	Ok
Vol +	Vol +
Vol -	Vol -
Mute	Mute
Play	Play
Pause	Pause

Original	Replacement
Stop	Stop
Menu	Menu
RDS/Display	Info
Repeat/Shuffle	Text
Prog	Shift + Sleep
Sound	Dual
Clock	AV
Sleep/Timer	Sleep

Original	Replacement	Original	Replacement
Power	Power	Stop	Stop
Open/Close	Eject	Menu	Menu
CD/FM	Yellow	RDS/Display	Info
Audio In/USB	Red	Repeat/Shuffle	Text
Dock	Blue	Prog	Shift + Sleep
Preset/Album	Up	Sound	Dual
Preset/Album	Down	Clock	AV
>>I	>>I	Sleep/Timer	Sleep
>>I	Right		
I<<	I<<		
I<<	Left		
OK	Ok		
Vol +	Vol +		
Vol -	Vol -		
Mute	Mute		
Play	Play		
Pause	Pause		