Original		Replacement		Original		Replacement	
DVD	Power DVD		Power	REPEAT	A-B/Repeat	SETTINGS OPT	Options
DISPLAY	Display	DISPLAY INFO	Info	CLEAR	Clear	CLEAR EXIT	Exit
VIDEO SYS	SYS Video	RETURN BACK	Back	PROGRAM FTS	FTS/Program	PROG SLEEP	Sleep
PBC ON/OFF	On/Off PBC	APP MEDIA	Media	SYSTEM MENU	Menu System	TOP MENU MENU	Menu
1	1	1	1	DISC MENU	Menu Disc	E-MANUAL D.MENU	D. Menu
2	2	2	2		Up		Up
3	3	3	3		Down		Down
4	4	4	4		Right		Right
5	5	5	5		Left		Left
6	6	6	6	OK	OK	OK	Ok
7	7	7	7	STOP/RETURN	Stop/Return		Stop
8	8	8	8	PLAY/PAUSE	Play	PLAY MODE	Play
9	9	9	9	PLAY/PAUSE	Pause		Pause
0	0	0	0	FWD	>>		>>
+10	+10	-/-- GUIDE	Guide	REV	<<		<<
TITLE	Title	FAV PRE-CH	Pre Ch	NEXT	>I		>>I
REPEAT	Repeat	REPEAT TEXT	Text	PREV	I<		I<<

Original	Replacement	Original	Replacement
FWD Slow	Ch +	Treble+	Shift + Ch +
REV Slow	Ch -	Treble-	Shift + Ch -
Subtitle	Subt		
Angle	Format		
Zoom	Eject		
Audio	Dual		
Search	TV/R		
Preview	Green		
Mode Sound	Yellow		
3D Sound	3D		
Power Speakers	Shift + Power		
1-2-3 Input	AV		
Vol +	Vol +		
Vol -	Vol -		
Mute	Mute		
Bass+	Shift + Up		
Bass-	Shift + Down		