Mandis shop

Philips REMCON1664

Original		Replacement	
EJECT	Eject	SURROUND	Eject / Surround
STANDBY/ON	Standby/On		Power
MENU	Menu	HOME MENU	Menu / Home
STATUS/EXIT	Status/Exit	CLEAR EXIT CANCEL	Exit / Cancel / Clear
CLEAR	Clear	SHIFT + CLEAR EXIT CANCEL	Shift + Exit / Cancel / Clear
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD - STB 3	3
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
7	7	AUX - HDD 7	7
8	8	USB 8	8
9	9	BLUETOOTH 9	9
SLEEP	Sleep	TIMER SLEEP	Sleep / Timer
0	0	HDMI - SAT 0	0
SYSTEM	System	LIST SMART	Smart / List

Original		Replacement	
RECORD/OTR	Record/OTR	REC MODE	Rec / Rec Mode
	Up		Up
	Play	SLOW	Play / Slow
STILL	>I</Still	STEP - FREEZE	Pause / Step / Freeze
	<<	TUNE-	<< / Tune-
	Left		Left
	Right		Right
	>>	TUNE+	>> / Tune+
P+	P+	CH PAGE	CH+ / Page+
	Stop	HOLD	Stop / Hold
	Down		Down
	Vol+	VOL	Vol+
P–	P-	CH PAGE	CH- / Page-
MUTE	Mute	DIMMER MUTE	Mute / Dimmer
	Vol-	VOL	Vol-
SV/V+	Red/SV/V+	NETFLIX SEARCH	Red / Netflix / Search
SMART PICTURE	Green/Smart	APP REPEAT	Green / APP / Repeat

Picture

https://alle-fernbedienungen.de/en/1068090-93743-replacement-remote-control-for-Philips-REMCON1664.html

Original	Replacement
Green/Smart	Picture / Format
Yellow	Yellow / YouTube / Repeat
Blue/Index	Blue / Prime Video / Random
[=i]	Info / Angle
Text	Text / Goto
[=?]	D.Menu / Top
[=♦]	Zoom / Size
[=x]	TV/Radio /
[=o]	Setup / OPT /
[=+]	AV / Input / RDS

Original	Replacement