Mandis shop

Pioneer CU-XC005

Original		Replacement	
	Direct Play (--)	NETFLIX SEARCH	Red / Netflix / Search
	Direct Play OO	APP REPEAT	Green / APP / Repeat
	Direct Play Y	YouTube REPEAT A-B	Yellow / YouTube / Repeat
	Direct Play [*]	Prime Video RANDOM	Blue / Prime Video / Random
MENU	Menu	HOME MENU	Menu / Home
SOUND	Sound	TITLE SOUND	Sound / Title
	>>	TUNE+	>> / Tune+
TIMER	Timer	TIMER SLEEP	Sleep / Timer
CANCEL	Cancel	CLEAR EXIT CANCEL	Exit / Cancel / Clear
	I<</-	PRESET-	I<< / Preset-
	Stop	HOLD	Stop / Hold
	>>I/+	PRESET+	>>I / Preset+
SET	Set	OPT-TOOLS SETUP	Setup / OPT /
DISPLAY/ CHARACTER	Display/Character	ANGLE INFO	Info / Angle
	<<	TUNE-	<< / Tune-
AUX	AUX	AUX - HDD 7	7
DISPL DOWN	Display Down	CH PAGE -	CH- / Page-

Original		Replacement	
UP	Display Up	CH PAGE +	CH+ / Page+
	Power		Power
	Vol-	VOL -	Vol-
	Vol+	VOL +	Vol+

https://alle-fernbedienungen.de/en/Pioneer/1065991-5307-replacement-remote-control-for-Pioneer-CU-XC005-AXD7170.html