Original	Replacement	Original	Replacement
Standby	Power	Menu	Menu
Mute	Mute	Exit	Exit
ATV	Smart	Up	Up
Tv/Radio	TV/R	Down	Down
Tv Guide	Guide	Right	Right
USB	Media	Left	Left
Rec	Rec	OK	Ok
I <<	I <<	1	1
>>I	>>I	2	2
Stop	Stop	3	3
<<	<<	4	4
>>	>>	5	5
Play	Play	6	6
Pause	Pause	7	7
Rec List	List	8	8
AV/Source	AV	9	9
i/Info	Info	0	0

Original		Replacement	
	Back	RETURN BACK	Back
	FAV	FAV PRE-CH	Pre Ch
	Vol +	+ VOL	Vol +
	Vol -	VOL –	Vol -
	Subtitle	AD SUBT	Subt
	Aspect	ECO 3D	3D
	Audio	SOUND DUAL	Dual
	Sleep	PROG SLEEP	Sleep
	CH+	+ CH	Ch +
	CH-	CH –	Ch -
	Red	A	Red
	Green	B	Green
	Yellow	C	Yellow
	Blue	D	Blue
	Text	REPEAT TEXT	Text
	Index	SETTINGS OPT	Options
	Reveal	E-MANUAL D.MENU	D. Menu

Original		Replacement	
	Power/Display	SHIFT +	Shift + Power
	P. Mode	SHIFT + PICTURE FORMAT	Shift + Format
	Size	PICTURE FORMAT	Format
	Hold/Lang	SHIFT + SOUND DUAL	Shift + Dual
	S. Mode	ZOOM	Eject